


Ceiling Fan Remote Control User Manual

Model: RT006

Functions of the button on the remote-control transmitter:

- ① Fan On/ Off
- ② Fan Speed Control, total 6 speeds
- ③ Light Ambient
- ④ Light control + (Bright) /- (Dim)
- ⑤ Fan Rotate Direction: Clockwise and Anti-clockwise
- ⑥ Timer (1Hr, 2Hrs or 4Hrs)
- ⑦ Variable Breeze
- ⑧ Pairing Mode (By pressing 1H and 4H buttons simultaneously)
- ⑨ LED indicator



Attention

1. When the remote-control transmitter cannot control the receiver, please check whether the batteries are installed properly or not. Also check the power level of the batteries. It may affect the control and decrease the signal transmission if the power level of the batteries is too low.
2. When the transmitter cannot control the receiver, please check if there are any similar products nearby. The similar remote-control products transmit radio waves at the same time, which will cause interference.
3. Replace the batteries if the power level of the battery is too low. Leakage from the battery may cause damage of the transmitter. Please

dispose of used battery properly and keep battery out of the reach of children.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.