

User Manual

D3000

Alarm Clock with Light for Kids

Button Function

1 2	Alarm Clock 1 2 Setting
	Time Display Setting
- +	Time/ Volume Setting
Power On/Off or Snooze	
Play/Pause Music	
M	Music/ Bluetooth Mode
	Sleep Timer
	Light Mode
	Light Brightness / Sun & Moon Icon Setting

Lighting Effects

Charging Indicator

Time

Alarm Clock 1

Alarm Clock 2

Sleeping Mode

1 2 ALARM SETTING

1. Press and hold 1 button for 2 seconds to start alarm setting.
"HOUR" flashes first. Then press + - to set the hour.
88:88

2. Short press 1, "MINUTE" flashes. Then press + - to set the minute.
88:88

3. Short press 1, then press + - to choose "ALARM COLOR (AC)" (with 9 types).

4. Press 1, then press + - to choose "ALARM LIGHT BRIGHTNESS (AL)" (with 3 types).

5. Press 1, then press + - to choose "ALARM SOUND (AS)" (with 14 types).

6. Press 1, then press + - to set the "ALARM VOLUME (AV)" (0 -- 30).

7. Press 1, again. "ALARM CLOCK 1" has been set (Monday -- Sunday).

Tips:

- During the above steps, if user does not have any operation within 30 seconds, the alarm setting will be automatically confirmed and end.
- After setting the alarm, user can short press 1/2 to turn on or turn off the alarm (Monday -- Sunday) they set.
- When the 1/2 icon is displayed on the screen, the alarm clock is on everyday.

Package Includes:

- 1. Alarm Clock
- 2. Type-C Charging Cable
- 3. User Manual

Notices:

- Please keep this manual for future reference.
- Do not press two or more buttons at the same time.

TIME SETTING

1. Press and hold button for 2 seconds to start time setting.

2. Press + - to choose 12-hour clock or 24-hour clock.

3. Short press then press + - to set the hour.

4. Press then press + - to set the minute.

5. Press again to finish the setting.

Tips:

- How to adjust the display brightness of and the time ?
Short press button in sequence. 3 levels for you to choose:
 - >> Brightest (suitable for daytime)
 - >> Medium (suitable for night)
 - >> None (black screen)

POWER/SNOOZE BUTTON

When the alarm sounds, user can press any button to stop the ringtone except for the power/snooze button.

This center button has both power on/off and snooze functions.

- POWER ON/OFF: press and hold button for 3 seconds.
(Tip: Long press button to turn off the night light function.)
- SNOOZE FUNCTION: when the alarm rings, press button, and the alarm will ring again after 5 minutes for no more than 3 times in total.

NIGHT LIGHT / ATMOSPHERE LAMP

1. Press and hold button for 2 seconds to turn on/off the night light function.

2. Short press button in sequence to choose the lighting effects. (with 13 types).

3. Short press button to adjust the brightness of the light (4 options: low/ medium/ high/ none).

SUN&MOON ICON SETTING

1. Press and hold button for 2 seconds. Sun icon and "HOUR" flash. Then press + - to set the hour.

2. Short press, "MINUTE" flashes. Then press + - to set the minute.

3. Short press, Moon icon and "HOUR" flashes. Then press + - to set the hour.

MINUTE

4. Short press, "MINUTE" flashes. Then press + - to set the minute.

5. Press, again to finish the setting.

For example:
If you set "06:00" for and "20:00" for, then sun icon will stay on during "06:00~20:00", and moon icon will stay on during "20:00~06:00".

Tips:
If the device is powered off, you need to reset this function when the device is powered on again.

MUSIC PLAYER

Short press button to enter Bluetooth mode or white noise mode.

The device name of this alarm in Bluetooth mode: D3000.

Long press + - to adjust the volume (0-30) of music.

SLEEP TIMER

Short press + - to play the previous song or the next song.

Short press to play or pause the music.

This function is to stop playing music and turn off the night light at a fixed time, but does not affect the time display function.

1. Press and hold button for 2 seconds to start the setting.

2. Short press button in sequence to choose the time you want to stop the music and night light. Make your choice and wait for 2~3 seconds, then the setting is complete.

Four Options:

- after 30 minutes;
- after 60 minutes;
- after 90 minutes;
- to turn off the "sleep timer" function

Thank you for purchasing our products!

In case your paper manual is lost, you can contact us through the shopping website to get a pdf version.

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or ate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modi cations to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.