

DHL in-ear



Wireless Earbuds User Manual

Getting Started

Remove the earbuds from the box.
Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Pairing mode-Auto pairing:

Pairing name: DHL in-ear

Remove your earphones from the charging station, they will turn on and pair with one another automatically. Once the earphones are paired either LEFT or RIGHT earphone will flash red and blue alternately waiting to be paired to a device. The earphones will appear as "DHL in-ear" in the list of available Bluetooth devices. Select it and connect. When you put the earphones back in the charging station they will turn off automatically and begin to charge if needed.

When your earphones are off, press and hold the button for 3 seconds to turn on your earphones. If your earphones are already on, press and hold the button for 5 seconds to turn off your earphones.

Key function:

Long press for 3 seconds	Power on
Long press for 5 seconds	Power off
Short press	Music pause/Music play/Answer the phone/Hang up
Double press	Skip songs
Triple press	Volume + / -

Indicator light status

Pairing Mode	Working	Charging	Full charging
Light flashes in red/blue	Blue light blinks slowly	Red lights bright constantly	Blue light bright 30 seconds constantly then off

Specification

Bluetooth version: 5.0
Bluetooth frequency: 2402-2480MHz
Frequency response: 20Hz-20kHz
Max transmitted power: 4dBm
Power supply: Built-in battery
Battery capacity: 35mAh/earbud, 300mAh/charging case
Charging voltage: DC 5V
Operation range: 10m
Playing time: Up to 13+ hours with charging station
Charging time: 1-2h

SAFETY INSTRUCTIONS

- The battery shall not be exposed to excessive heat such as sunshine.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.



Guidelines for protection of the environment.
This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances.
This symbol on appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement. the device can be used in portable exposure condition without restriction