# Wireless Cast

Before using this product,
please read this user manual carefully and keep it in a safe place

Product Introduction

Thank you for choosing our products. You can fully understand the functions and operation methods of the equipment by reading this manual.

This product mainly realizes the function of small screen transmission and large screen transmission. The pictures, audios, videos, documents and games on the mobile terminal can be simultaneously pushed to the TV and projector with HDMI socket to watch on the big screen. It is suitable for home entertainment, business meetings, teaching training and other fields, so that users can get better Audiovisual experience.

packing list

| Projector | HDMI | Micro-USB | Manual/Warranty |

feature of product

1. Fast boot in 10 seconds；
2. WeChat scan code quick distribution network；
3. Support Huawei mobile phone computer mode；
4. Support wireless projection for multiple applications, suitable for Android/Apple devices；
5. Support Apple mobile device mirroring same screen display, suitable for iphone, ipad, mac notebook, can cast images, videos, games, etc .
6. Support Android mobile device connecting on the same screen display, you can cast pictures, videos, games and other content；
7. Support WIN10 notebook mirror display on the same screen, you can cast PPT, WORD, web pages and other content；

Performance parameter

Main chip	A11winner H3
Resolution	4K/30Hz
WIFI work frequency	5G/2.4G
RAM	256MB
storage	16MB
Projection Agreement stand by	DLNA、Miracast、AirPlay
power supply	5V/1A Micro-USB

Connected for the first time

Method one- WeChat scan the distribution network
Scan the QR code on the homepage of the screen projector, fill in the name and password in the "WIFI Information" according to the prompts, and connect.
Method Two- URL distribution network
A. Turn on mobile Wi-Fi -> Enter WLAN search and connect to CITIfuture-xxxx ->
Enter the password 12345678-> if prompted whether to continue using this WLAN, click "Use";
B. Enter the address 192.168.69.1 in the mobile browser and enter -> Click "Wifi", -> Choose commonly used WIFI-> enter password -> Click "CONNECT".

Change network

Make sure that the phone and the projector are connected under the same WIFI -> Enter the upper right corner of the screen projector homepage in the mobile browser "Set Address" and enter -> After entering the webpage, select "WIFI" -> Select the WIFI that needs to be replaced-> enter password-> Click "CONNECT".

Schematic diagram

Product virtual map, the appearance is subject to the actual product

HDMI interface
Power indicator
Micro-USB interface

Reset button

Reset button：Long press the 6S button in the power-on state and release it, and the projector will enter to restore factory settings; Power indicator: It turns blue after power-on.

Functions and instructions

1、wireless same screen

1) Android device video/game on the same screen
Enter the screen projection function in the phone/tablet, search for and connect to the screen projection device (Mirror same screen selection⟦⟧ CITIfuture-xxxx、Picture or video push selection⟦⟧CITIfuture-xxxx) .Path reference for screen projection function of different brands of mobile phones:
Huawei: Drop-down menu -> wireless projection/multi-screen interaction (Huawei phones that support computer mode can select computer mode after the same screen) ；
Millet: Drop-down menu -> cast screen；
OPPO/VIVO:Drop-down menu -> Smart screencast；
other：Settings -> More connection methods -> Mobile phone screencast.
2) Apple device video/game on the same screen
On order to ensure the smoothness of the same screen, it is recommended that both the mobile phone and the projector are connected to use under 5G WiFi
Make sure that the phone and the projector are connected to the same WiFi-> control center -> Screen mirroring -> Choose CITIfuture-xxxx .
3) WIN10 Office projection
Press WIN+K at the same time -> select CITIfuture-xxxx .
4) Macbook Office projection
Right-click on the desktop to enter "Display Settings"-> Scroll down to multi-monitor settings -> Go to "Connect to wireless display Finder" -> Search and select CITIfuture-xxxx.Go to "Connect to a wireless display" -> Search and select CITIfuture-xxxx.

2、TV projection

Open the video App, enter the video playback window, and click the TV projection icon⟦⟧. Search and select CITIfuture-xxxx, you can cast screen.

Name and content of hazardous substances in the product

Part Name	Toxic and harmful substances or elements					
	Pb	Hg	Cd	Cr6+	PBB	PBCE
Host	×	○	○	○	○	○
Cable assembly	×	○	○	○	○	○
Power Adapter	×	○	○	○	○	○
Plastics and polymers	×	○	○	○	○	○
Metal parts	×	○	○	○	○	○

The number in this logo indicates that the environmental protection use period of the product under normal use is 10 years.

○：indicates that the content of the toxic and hazardous substance in all the homogeneous materials of the part is below the limit specified in the GB/T26572 standard.

×：indicates that the content of the toxic and hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirement specified in GB/T26572.

Warranty description

*Retained by the user, no replacement if lost

Three Guarantees Range

If the product has quality problems within 7 days from the date of purchase, you can choose to return or repair it;
If the product has quality problems within 15 days from the date of purchase, you can choose to exchange or repair;
The host is guaranteed for one year from the date of purchase;
The accessory products are guaranteed for three months.

The scope of the three guarantees is not allowed (the implementation of paid maintenance services)
Normal paint falling, discoloration, abrasion and consumption during product use;
Machine failure caused by consumers' disassembly, maintenance or improper storage without the permission of the company；
Machine failure or damage caused by natural disasters or force majeure and other non-product quality factors;
The machine number filled in the consumer purchase invoice or warranty card is inconsistent with the product body code;
The product certificate and the body tamper-proof sticker are damaged;
Those who do not have the purchase invoice and warranty card, or the warranty card has not been filled in or the dealer' s seal has not been stamped.

Warranty Card

username _____

User address _____

telephone number _____

Product number _____

Order number _____

Purchase date _____

Invoice number _____