


145 mm

110 mm

Smart speaker instructions



Product parameters

Product name: Smart speaker

Product model: M5-Z2

Rated voltage: 5V


Speaker power: 5W

Battery capacity: 2000mAh Li-Polymer

Product weight: 422g



Input parameter: DC 5V \equiv 1A

Product size: \varnothing 72x201mm



\varnothing 72 mm

201 mm



Smart speaker

①. Speaker switch:
1> Long press for 3 seconds to turn on and enter the Bluetooth connection mode; long press again to shut down; if the Bluetooth connection is unsuccessful, it will automatically shut down after 5 minutes.
2> Short press to pause; short press again to play.

②. Volume+ /next song:
Short press the next song, long press the volume to increase.

③. Volume- /previous song:
Short press the previous song, long press the volume to decrease.

④. Bluetooth connection indicator:
Red and blue lights flash alternately and quickly, turn off the lights after successful connection.
Charging indicator:
Red light when charging, blue light when fully charged.

⑤. Battery indicator (displayed from left to right)
1> electricity \geq 75%, LED1-LED4 are always on
2> 50% \leq electricity<75%, LED1-LED3 are always on
3> 25% \leq electricity<50%, LED1-LED2are always on
4> electricity<25%, LED1 are always on, Turn off the lights when the battery is low.

⑥. Charging port: DC 5V \equiv 1A.

⑦. Combination interface.

⑧. silicone suction cup.
1> Press the product on the flat and smooth table, which is more stable and not easy to dump.
2> It has the function of anti-skid and cushioning.

Precautions

Note: Please do not open the casing of this product, please refer to qualified maintenance personnel for maintenance.

1>Please install this product according to the instructions.

2>Please clean this product with a dry cloth only.

3>Do not use this product near water.

4>Do not block any sound holes.

5>Do not place it near any heat source, such as radiators, hot air regulators, stoves or other speakers (including amplifiers) that generate heat.

6>Please protect the power cord, avoid being stepped on or squeezed, and do not pull the plug, socket and the outlet of the product.

7>Please use the accessories or accessories specified by the manufacturer.

8>Do not expose the battery to excessive heat, such as sunlight, fire, etc.If the battery is incorrectly replaced, there is a danger of explosion. If you need to replace it, you can only replace the battery of the same type or by the manufacturer the battery of the recommended model. Please dispose of the replaced battery according to the manufacturer's requirements.

9>Please unplug the power plug during a thunderstorm or when the product is not used for a long time.

10>Please should connect to a power supply within the specified voltage range.

11>Do not expose this product to liquids or splashes, and do not place utensils such as vases containing liquids on top of this product.

12>Please place the product in a stable and flat place to avoid damage to the product due to dumping.

13>For all maintenance matters, please refer to professional maintenance personnel. If the product is damaged, it should be repaired, such as the power cord or plug is damaged, liquid splashed or objects fell into the product, the product is rained or damp, and cannot work normally, or falling from heights.

Warranty terms and conditions products purchased from directly-operated stores and authorized distributors enjoy a one-year warranty from the original purchase date.The purchase certificate can prove that the product was purchased in an approved sales channel, and it can enjoy free repair or replacement services during the warranty period.

The stated warranty does not apply to the following situations:

1>The product is not used in accordance with the instructions of the product, or the parts that are not produced or approved by the original factory are used.

2>Dismantling by yourself, or dismantling by an unauthorized repair center, causing damage.

3>The cause of the failure is caused by negligence or force majeure, such as accidents (such as fire, flooding, damp, external force extrusion and falling, etc.), natural disasters such as (such as lightning, earthquake, typhoon, etc.) caused by failure or damage.

4>During use, the natural consumption, damage, wear and aging of consumables or parts (such as batteries, etc.).

5>It is invalid for any fakes.

6>Other items not specified shall be implemented in accordance.

with the relevant laws and regulations of the country or region where the product is sold, If you need to obtain maintenance and other services during the product warranty period, please contact the dealer or retailer of the purchased product directly, and provide the purchase invoice and proof of the original purchase date.

Harmful substance

Harmful materials	Part name	Printed circuit assembly	Metal parts	Plastic parts	Speaker	Battery	Wire
	Pb	○	○	○	○	○	○
	Hg	○	○	○	○	○	○
	Cd	○	○	○	○	○	○
	Cr (VI)	○	○	○	○	○	○
	PBB	○	○	○	○	○	○
	PBDE	○	○	○	○	○	○

This form is compiled according to the regulations of SJ/T11364.
O:Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T26572-2011.
X:Indicates that the hazardous substance contained in at least one of the homogeneous materials of the part exceeds the limit requirement specified in GB/T26572-2011.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement.

Consumer information

Name:	Postal code:
Address:	Contact number:

Sales unit information

Name:	Seal:
Postal code:	Sale date:
Contact number:	Invoice number:
Address:	

Maintenance organization information

Name:	Contact number:
Address:	Postal code:

Maintenance records	fault situation/fault reason /processing result	Calibration date	Repairer's signature