


# Smart Remote User Manual

## 1.Product Diagram




1

## 2.How to Pair Automatically:

1. Remove batteries of your original Fire TV remote controller and unplug power cable from Fire TV Box/Stick, after 15 seconds, plug back the power cable.

2. Once Fire TV is on main menu (as shown in the picture below) wait for 1 minute and then press and hold button for 10 seconds or more until LED light starts to flash quickly. Now your Smart Remote control is in pairing mode.




3. Smart Remote will now pair with Fire TV within 30 seconds. Once paired ,LED light will be off.

2

## 3.How to Set Power /Vol+ / Vol- /Mute Buttons

(1) Go to Fire TV Setting, and choose Equipment Control.



(2) Go to Manage Equipment.



3

(3) Go to TV.



(4) Go to Change TV.



4

(5) Choose Change TV.



(6) Choose Yes.



5

(7) If you can not operate TV's Power/Vol+/ Vol-/Mute with Fire TV's default code, Please Click No.




(8) Then choose TV's brand on the MENU.




6

(9)Press Power on your Fire TV remote.



(10)Select Yes, If you can control the TV volume up or down by pressing the volume keys on the Fire TV remote.



7

(11) If the 1st choice not succeeds, click No, the system will change to 2nd code choice to meet the Power, Vol+, Vol- and Mute.



If 2nd still fails, Click No, system will go to 3rd code, if all the codes not succeeds, that means this brand TV set's code not stored in the Fire TV Stick data System.

**NOTE:**If the remote does not control your TV or soundbar correctly, please use the IR learning function to program the power and volume buttons.

8

## How to Set IR Learning

The Smart Remote Control is with 4 IR Learning Buttons (Power, Mute, Vol+, Vol-)supports static IR code learning functions,How to learn(take the Smart Remote's Power button and Mute button IR learning as examples).

### Power button IR learning steps:

1. Press the Smart Remote's Button and Button at the same time for 2 second. The red LED at the front of the Smart Remote will be long lighting. And now the Smart Remote is in the status of IR Learning.

2. Put the Smart Remote's IR sender directly face to your TV Set remote's IR sender. Press 2 second TV Set's Remote Power button that you want to learn. When Smart Remote receives the TV Set's Remote power button code, its red LED will be shining 3 times quickly. That means learning succeeds and is saved automatically.



TV Remote

9

### Mute button IR learning steps:

1. Press the Smart Remote's Button and Button at the same time for 2 second. The red LED at the front of the Smart Remote will be long lighting. And now the Smart Remote is in the status of IR Learning.

2. Put the Smart Remote's IR sender directly face to your TV Set remote's IR sender. Press 2 second TV Set's Remote Mute button that you want to learn. When Smart Remote receives the TV Set's Remote Mute button code, its red LED will be shining 3 times quickly. That means learning succeeds and is saved automatically.

**Remark: Press button and the button(one of the 4 IR Learning Buttons) that you want to learn for 2 second at the same time, the Smart Remote Control will be into IR learning mode.**

**Clear IR code:** Press the Smart Remote's Button and Button at the same time for 3 second, Red LED will be shining 3 times quickly.

**NOTE:**The button codes on other remotes that to be learned must be Static IR code, if Dynamic ones, can not be learned.

10

## How to Pair a Replacement Remote to You Fire TV

If your original Fire TV RemoteControl already connected with Fire TV Stick, this Smart Remote then can not connect with Fire TV Stick automatically and you need to pair it manually.

(1) Go to Fire TV Setting, and choose Controllers&Bluetooth Devices.



(2) Go to Amazon Fire TV Remote.



11

(3) Go to Add New Remote.




(4) Press button for 10 seconds, Smart Remote's LED will flash quickly and go into Pairing Mode, now Smart Remote's pairing name will be Fire TV Remote, click Connect, when LED off, now pairing success.



12

## How to Reset an Fire Stick Remote

To reset a Fire TV remote, UnPlug your Fire TV device from power for 60 seconds. Then press the left, menu, and back buttons on your remote for 12 seconds. next, remove the batteries, plug your Fire TV device in and wait 60 seconds. Finally, insert your batteries and press the home button.



Note:The used batteries with low battery may fail to pair or hot, New batteries are recommended for first paring.

13

**FCC Warning Statement:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Radiation Exposure Statement**  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

14