Radio+

DD1520H DD1522H

Emitter Instruction

Version: A/00

Instruction Of Buttons







DD1520H

DD1520H DD1522H

Single-channel emitter

15-channel LCD emitter

Back

Technical specification

Battery: 3V (AAA battery×2)	Battery life: >2 years	Center Frequency: 433.92MHz
Working temperature: -5°C ~ 50°C	Transmission power: 10 mW	Radio range: 35 meters

Warning

- 1, Emitter couldn't expose to moisture or be striked heavily, or else the emitter life will be affected;
- 2, If the emitter is not so sensitive or the radio range becomes shorter, pls check whether to change the battery;
- 3, If the voltage is less than 2.6V, there will be a low voltage indication;
- 4, Under uni-directional mode, if you press any button more than 20S, while under bi-directional mode, you press any button 55, the emitter will stop sending radio signals;
- 5, It's forbidden to use different type battery to avoid any dangerous risk;
- 6, Dispose of used batteries properly.

Max. Channels Adjustment Of DD1522H

Note: In the setting status, press UP or DOWN button to exit quickly. Repeat the same process if you want to adjust the Max. channels.



RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

(2) this device must accept any interference received,

including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.


NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Uni-directional / Bi-directional Mode Switch Of DD1522H



Combination Button Lock / Unlock Operation Of DD1520H

Note: 1,The factory default is unlock status, repeat same operation to switch status circulaly. 2,When the combination buttons are locked, if you press the combined buttons, the emitter won't send any signal and LED won't flash. 3,Only the transmitting code will be affected if the combination buttons are locked.



Combination Button Lock / Unlock Operation Of DD1522H

Note: 1,80th the two P2 buttons on the back are operable. 2,The factory default is unlock status, repeat same operation to switch status circulaly. 3,Under lock status, the combination buttons don't work; Under unlock status, the combination buttons will work normally. 4,Only the transmitting code will be affected if the combination buttons are locked. 5,If there is no operation for 10 seconds, it will automatically exit the setting status.

