

WRS14 Remote Control Instructions


1. Product Overview

Product Name: Remote Control
Product Model No.: WRS14
FCC ID: 2BA76WRS14MNT014

2. Environment requirement

Operation temperature: +10°C~+40°C.
Storage temperature: -10°C~65°C.
Operating Humidity: 10%~80%RH, non-condensing.
Storage Humidity: 10%~85%RH, non-condensing.

3. Directions for Operation



How to pair the bed with the remote control

STEP 1: Ensure that the remote control is functioning properly.

STEP 2: Unplug the AC power cord from the power source. If 9V backup batteries (6LR61 alkaline batteries) were installed in the power supply, remove them.

STEP 3: Press the PAIR button on the back of the remote control, the indicator light will stay on for about 4 seconds and then turn off. Release the button.

STEP 4: The control box is powered on and emits a beep sound before pairing is completed.

How to Setting Programmable Position:

STEP 1: Adjust the bed to the desired memory location.

STEP 2: Press and hold the  button in the upper left corner for about 3 seconds, and the indicator light will change from constantly on to flashing. During the flashing process, press M1 or M2 button to complete the position memory, and the indicator light will turn off.

How to charge the remote control

There is a USB port on the lower end of the remote control, which can be plugged in to charge the remote control.

There is a solar charging panel on the surface of the remote control, which can be charged using solar energy.

4. Matters needing attention:

- 4.1 The function will only work normally in proper working power conditions.
- 4.2 Remote Control needs DC 3.7-3.85V powered by li-ion batteries.
- 4.3 The control box is needed for proper control.
- 4.4 If problems are identified, they must be treated by professional personnel.

5. Additional attention for user:

5.1 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/ TV technician for help.

5.2 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

5.3 For Intentional and unintentional radiators the manual shall caution the user and manufacturer that changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

