


Getting Started:

- 1) Read all enclosed Safety Instructions and cord tags before starting.
- 2) Plug your tree light into a power source.

Using the Control-Box



Functions

Press the Function button on the controller box to switch between the following light effect modes.

- 1) Steady white
- 2) Steady multi
- 3) Steady red
- 4) Steady green
- 5) Steady blue
- 6) Color Changing White to Multi
- 7) Color Changing Red to Green
- 8) Color Changing White to Blue
- 9) Color Changing All 5 colors
- 10) Off

Press the "Function" button on the control box in order to set your desired lighting function.

- You can press any control box within range (50 feet) of your other lights in order to control the lights wirelessly. Press the function button, all your lights will change functions automatically - as long as they are on the same Channel.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.