

**X9H****X9H**

Thank you for purchasing X9H. You are now just a step away from the realm of Nirvana. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time varies depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology, TF Card & AUX wire compatibility, this portable speaker has been designed for a smooth interface that requires the minimal of efforts.

TWS:

You can connect two X9H and virtually forge them into one speaker for a greater impact. For TWS connection:

Turn on both the speakers

- Press and hold MFB on one of the two speakers for about 2 seconds until you hear a beep
- After releasing MFB, it may take a few more seconds for the speakers to connect
- Activate the phone's Bluetooth function and search for "X9H" to establish pairing

Charging:

- X9H beeps once every 5 minutes when the battery is low. After three such indications, the speaker automatically turns off
- Utilize the provided charging cable to charge the speaker
- The LED indicator turns into steady red while charging; the same goes off as soon as the speaker gets fully charged

Note:


Please avoid using the speaker while it is in charge as it may decrease the battery's performance

Specifications:

Speaker Type	Portable Wireless Speaker
Bluetooth Version	V5.3
Working Range	10m
Speaker Size	1.96"
Water Resistance	IPX6
Supported Profiles	Bluetooth V5.3+BR+EDR
SNR	80dB
Frequency	20Hz-20kHz

Package Contents

- 1x Bluetooth Speaker
- 1x Charging Cable
- 1x Audio Cable
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue

**Power ON/OFF**

You may long press the power button to switch the speaker ON/OFF.

Functions:

- **Answer Incoming Calls:** Short press the MFB (*Multifunction Button)
- **End Call:** Short press the MFB once to end calls
- **Reject Incoming Calls:** Long press the MFB for 2 seconds
- **Redial:** Double press the MFB to redial the last contacted number
- **Switch Modes:** Short press the power button to select modes (Bluetooth/AUX/TF Card)
- **Volume Increase:** Short press the "+" button in steps for increasing the volume
- **Volume Decrease:** Short press the "-" button in steps for decreasing the volume
- **Play/Pause:** Short press the MFB to play or pause the tracks
- **Previous Track:** Long press the "-" button for returning to the previous track
- **Next Track:** Long press the "+" button for skipping to the next track

Bluetooth Connectivity:

- Turn the speaker on. Its LED indicator blinks blue until the pairing is done
- Activate the phone's Bluetooth function and search for "X9H". As soon as the speaker gets selected and paired by you, the connection gets indicated by a sound prompt.

Note:

- The speaker can automatically reconnect to the last paired device
- If you are having connection troubles, then remove X9H from the list of paired devices on your phone, keep the phone closer to the speaker and try pairing again

AUX Mode:

- You can switch to AUX mode by using the AUX cable to connect the phone and the speaker, and then short pressing the Power button
- In the AUX mode, you can control the audio playback via the media device/ phone

Warning:

- Please charge the speaker according to the charging norms mentioned on packaging to protect the battery
- Do not disassemble the product
- Do not submerge the product inside water
- Do not keep this product safe from coming in contact with any liquid
- Do not use the product in extreme temperatures
- Please keep the product away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume
- Don't try to dismantle/repair the product on your own.

Charging norms & Precautionary Guidelines:-	
1) Charger/Brick/Adapter	5V 1A
2) Cable/Wire	5V 1A
3) Standard Cable (35 strands) (Ø10mm diameter/ strand)	

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.