

# Wireless Microphone Manual



Model:Wirelessmicrophone V1

**WARNING**

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

**CAUTION**

Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

**CAUTION:** These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

**FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits

### Wireless Microphone Pairing (Mic):

1. Long press the **POWER** button on wireless microphone for 2 seconds.
2. Double Click Wireless Microphone button, enter pairing mode, the **White** LED is flashing.
3. Long press on speaker **CLOCK/Microphone pairing button**, for 5 seconds to pair wireless microphone, the white LED is flashing.
4. After a successful connection, both the **White** LED on the main unit and on the speaker will become a white solid.
5. The wireless microphone and speaker has been successfully connected and can be used.



Unscrew battery cover to insert or remove AA batteries.

### General specification :

Model No.: Monster Wireless Microphone

Distance between Speaker and Microphone : >10m

Polar pattern: Cardioid

Frequency response: 65 Hz-15 kHz

Signal-to-Noise(S/N)ratio:> 60 dBA

frequency range : 2.402~2.480G

THD: < 0.5%, typical

Playtime:Up to 30 hours

Microphone battery:2 x AA alkaline (included)

Dimensions and Weight :

Dimensions(WxHxD):  $\Phi$  50x233 mm/1.95"x9.16"

Weight: 247 g/0.54 lb