



Instructions for Tesla Box




1.Specification List



Interconnect box * 1




USB cable* 1



Instructions * 1


Different types of usb cable can be purchased according to your car

2. Connection between Box and Mobile Phone



Tesla Box supports multiple mobile phone interconnection methods:
Wireless CarPlay, Wireless Android Auto, Wireless CarLife, Apple /Android Mirroring


3. Box Interface Display



4. Connection Relationship




The mobile phone can be connected to the Tesla Bluetooth to use the original car audio.




After the first connection, the mobile phone will connect automatically next time.

4.1 · Box Power Supply



usb 5V power supply is used in Tesla box , and it is recommended to use the on-board charger interface for power supply

4.2. Connection Box and Tesla




The first step is how to connect the box:


Tesla machine needs to connect to the wifi hotspot of the interconnection box first, select and connect the box hotspot (named Tsl - ****) on the wifi connection interface of Tesla's large screen, and check "Remain connected in drive" in the wifi settings

The initial password is: 1234678

4.3. Open Tesla Browser




Step 1 . Open the browser as shown in the figure




**Step 2: How to connect the box with the machine :
Input the box domain name www.zbox link and click the favorites button ★ on the right to add the domain name to the favorites for easy use next time.**

4.4 · Connection between the Box and CarPlay




To use wireless CarPlay, it is needed to connect the box Bluetooth (named Tsl - *****)
After the first use, it will be automatically connected next time.

4.5 · Connection between the Box and Android Auto




To use wireless Android Auto, it is needed to connect the box Bluetooth (named Tsl - ****)
After the first use, it will be automatically connected next time.

4.6 · Connection between the Box and CarLife



To use wireless CarLife, it is needed to connect the box Bluetooth (named Tsl - ****)
After the first use, it will be automatically connected next time.


4.7 · AirPlay Connection between the Box and iPhone



Step 1: Switch the “CAST” on the page




Step 2: Connect phone with box wifi




Step 3: Enter the AirPlay and select the zj-airplay

5. OTA



Step 1: Connect the mobile phone to the box hotspot



Step 2: Input 3.3.3.3 in the browser and click “check for updates”

5. Warning

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Thanks



Beijing Zhijian Technology Co., Ltd.



186 1132 5210



product@zjinnova.com