




Quick Installation Guide

Manufacturer: Shenzhen Sihai jialan Electronic Technology Co., Ltd.
Address: 301, Building 2, Hongxin Industrial Park, No. 1303, Guangguang
Road, Xinlan Community, Guanlan Street, Longhua District,
Shenzhen, Guangdong, China
Website: www.szwonlink.com
Email: wonlinkservice@163.com

Model: WL-NE3503
WiFi Extender/Repeater
Version 1.0
HVIN: WL-NE3503




Existing WiFi Coverage

Sometimes your router does not provide the WiFi coverage you need.

Extended WiFi Coverage

Boosts the range of your existing WiFi & creates stronger signal in hard-to-reach areas.

Product Structure:



1. Unplug it in a thunderstorm to prevent damage.
2. Keep away from the heat source and keep ventilation.
3. Pay attention to waterproof during storage, transportation and operation.




Repeater Mode

2. Simple Installation Steps


2-1. Wait for the power indicator and WiFi indicator to light up after connecting the power.

2-2. Wait about 60s, connect to WiFi "WONLINK-XXXX-2G" or "WONLINK-XXXX-5G".

2-3. When the extender is setup for the first time, the configuration webpage will pops up automatically. If not, launch a web browser and enter "192.168.10.1" in the address field, enter the password "admin", Click "LOGIN".




- 2-4. Scan and select your WiFi.
- 2-5. Enter your WiFi password (The password must be same as your router password), click "Save Setting".
- 2-6. After the setup is complete, it will reboot automatically. Then go to your WiFi list, reconnect WiFi "XXXX-2G" or "XXXX-5G" (your new extender WiFi), the password is your original WiFi password, and enjoy the WiFi.





Warm Tips:

Combine WiFi: Turn on this option, it will automatically switch to high-quality band for better performance.



Sync your device: Turn on this option, the new WiFi will be same as your original WiFi and there is no need to reconnect the extended WiFi anymore.



1. What's the role of WiFi extender?

A: Boosts the range of your existing WiFi and creates stronger signal in hard-to-reach areas. Please note that it can't increase your WiFi speed of your router, the speed of the extending WiFi will be reduced.

2. Where should i place the WiFi extender?

A: We would suggest that after setting up successfully, please move this WiFi extender on the halfway between your router and your weak signal area. The location you choose to install it must receive a WiFi signal of a certain strength, otherwise it is prone to dropouts because the original WiFi signal is too weak.

3. How to reset the WiFi extender?

A: Press the WPS/Reset button of your extender for 10 seconds then release it, wait to restore factory settings, when you can search the initial WiFi signal of the extender again through your mobile phone or laptop, it means the reset is successful.

4. Why the WiFi keeps disconnecting?

A: The installation is too far away from the router, causing the WiFi signal received by the repeater to be too weak. If you still have WiFi disconnecting problem, please contact us via wonlinkservice@163.com.

5. After the setup is successful, connect to WiFi but cannot access the Internet?

A: There would be 3 reasons, setup unsuccessfully, WiFi password entered incorrectly, conflict with host router.

1. Connect the WiFi signal of the extender and re-enter the IP address to check the connection status. If it says "connecting" or "not connected", it means that the setting is unsuccessful, you can try to change the browser to setup.
2. WiFi password can not contain special characters, such as @, %, #, *, etc., and no more than 32 characters, if it does not meet this requirement, it is recommended that you change the host router's WiFi password and then configure.
3. Reboot the host router and reset the extender before configuring.

6. When logging in to the IP address, it prompts that the password is incorrect?

- A: 1. Repeater default user name: admin, default password: admin, confirm whether the password is entered correctly.
2. Cut off the power of the repeater, plug it in again, then restore the factory settings, connect the repeater WiFi, and log in to the IP again.

7. What if the WiFi extender has broken?

A: We always offer friendly customer service for every customer. If there have any problem, please don't hesitate to contact us via wonlinkservice@163.com, we will solve it as soon as possible.

Dear Valued Clients,

Thank you for purchasing WONLINK products. To protect your rights and interests in after-sales service, please read the following maintenance regulations.

The following does not belong to free maintenance, our company can provide paid service, please note:

- Damage resulting from improper installation/mounting, improper use or storage of the product, or failure to observe the operating instructions, and/or safety notes;
- Beyond the limited warranty;
- Unauthorized alteration, tearing up the product bar code;
- Without authorization to change the settings file or recompilation;
- Unexpected factors or human actions lead to product damage, such as improper input voltage, temperature, water mechanical damage, break, rust or oxidation product of serious etc;
- Other failures or damages not caused by product's design, technology, manufacturing, quality, etc.

If you have any questions, please contact us by E-mail wonlinkservice@163.com, we will help you as soon as possible.
Website: www.szwonlink.com
Email: wonlinkservice@163.com



Warning

1. Use the product safely to prevent Electric shock risk.
2. Do not use in humid environment.
3. Use supporting power supply to prevent product damage.
4. Use the product safely to prevent inflammable and explosive risks.

Certificate Of Qualification

Quality Inspector

Production Date

Executive Standard



RoHS
MADE IN CHINA



Packaged in a separate sealed container and placed in a dry environment



ISED Statement

English: This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.
To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this

equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Notes : LE-LAN devices are restricted to indoor operation only in the band 5150-5250 MHz. However, original equipment manufacturer (OEM) devices, which are installed in vehicles by vehicles manufacturers, are permitted.