



<p>How to Wear</p>  <p>What's in the Box</p>  <p>开/关机 开机: 长按多功能键3秒, LED灯闪烁。 关机: 长按多功能键3秒, LED灯闪烁。断开蓝牙连接3分钟后也会自动关机。</p> <p>Power On/Off Power On: long press the MFB for 3 sec, LED flashes. Power Off: long press the MFB for 3 sec, LED flashes. Also power off automatically 3 min after disconnecting the BT connection.</p> <p>オン/オフ 電源投入: 多機能キーを3秒間長押しすると、LED 信号が点滅し。 電源を切る: 多機能キーを3秒間長く押して、LED 信号が点滅して。Bluetooth接続を切断してから3分後にも自動的に電源がオフになります。</p> <p>恢复出厂设置 关机状态下, 长按多功能键10秒。</p> <p>Restore Factory Setting Press & hold the MFB for 10 sec under Power Off mode.</p> <p>出荷時設定の復元 電源を切った状態で、マルチファンクションキーを10秒間押し続けます。</p>	<p>开/关机 开机: 长按多功能键3秒, LED灯闪烁。 关机: 长按多功能键3秒, LED灯闪烁。断开蓝牙连接3分钟后也会自动关机。</p> <p>Power On/Off Power On: long press the MFB for 3 sec, LED flashes. Power Off: long press the MFB for 3 sec, LED flashes. Also power off automatically 3 min after disconnecting the BT connection.</p> <p>オン/オフ 電源投入: 多機能キーを3秒間長押しすると、LED 信号が点滅し。 電源を切る: 多機能キーを3秒間長く押して、LED 信号が点滅して。Bluetooth接続を切断してから3分後にも自動的に電源がオフになります。</p> <p>恢复出厂设置 关机状态下, 长按多功能键10秒。</p> <p>Restore Factory Setting Press & hold the MFB for 10 sec under Power Off mode.</p> <p>出荷時設定の復元 電源を切った状態で、マルチファンクションキーを10秒間押し続けます。</p>	<p>蓝牙连接 打开蓝牙菜单, 选择“RockShine R1”进行连接, 连接成功提示音。</p> <p>BT Connection Select “RockShine R1” in BT menu to connect, successful connection prompt tone.</p> <p>Bluetooth接続 Bluetoothメニューを開き、接続するには「RockShine R1」を選択し、成功のヒント音を接続します。</p>	<p>FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - - Reorient or relocate the receiving antenna. - - Increase the separation between the equipment and receiver. - - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - - Consult the dealer or an experienced radio/TV technician for help.</p>
<p>上/下一曲 上一曲: 长按功能键-。 下一曲: 长按功能键+。</p> <p>Previous/Next Previous Track: Press & hold the Button-. Next Track: Press & hold the Button+.</p> <p>上/下の曲 前の曲: ファンクションキー+を長押しします。 次の曲: ファンクションキー-。</p> <p>音量加/減 音量加: 单击功能键+。 音量减: 单击功能键-。</p> <p>Volume Up/Down Volume Up: click the Button+ once. Volume decrease: click the Button- once.</p> <p>音量プラス/マイナス 音量プラス: ファンクションキー+をクリックします。 音量減: ファンクションキー-をクリックします。</p>	<p>充电 请使用DC 5V适配器为设备充电, 充电时绿灯闪烁。一次后常亮, 充满电白灯常亮。</p> <p>Charge Please use DC 5V adapter to charge. The green light will be on after flashes once during charging, and the white LED will be on if fully charged.</p> <p>じゅうさん DC 5Vアダプタを使用して機器を充電してください。 充電時に青信号が1回点滅した後は常に点灯し、満タンの白ランプは常に点灯します。</p> <p>音量报警 当电池电量低于5%时, 每隔4分钟绿灯闪烁3下, 播放音量报警提示音。</p> <p>Low Battery 当电池电量低于5%时, the green LED flashes 3 times every 4 mins with the volume alarm tone.</p> <p>ていでんりょうけいひょう バッテリの電力量が5%未満の場合は、4分ごとに青信号が3回点滅し、音量アラームのビーピ音が再生されます。</p>	<p>重要说明 1.长时间大音量听音乐可能会影响听力。强烈建议中等音量, 避免长时间超过80%音量使用; 2.长时间佩戴耳机可能会影响对周围环境的感知, 使用耳机时多加注意; 3.勿将耳机改装或改装耳机, 否则可能导致耳机故障或损坏; 4.切勿抛扔, 压压耳机或旋转耳机; 5.勿将耳机放入火炉或使用高于5V的充电电压; 6.不要让3岁以下儿童使用, 内包含小零件; 7.请勿将其丢弃于生活垃圾, 如想丢弃请将其送至当地的电器设备回收站; 注意:若用户因违反以上警告内容造成的人身财产损失,本公司不承担责任。</p> <p>重要說明 1.长时间大音量听音乐可能会影响听力。强烈建议中等音量, 避免长时间超过80%音量使用; 2.长时间佩戴耳机可能会影响对周围环境的感知, 使用耳机时多加注意; 3.勿将耳机改装或改装耳机, 否则可能导致耳机故障或损坏; 4.切勿抛扔, 压压耳机或旋转耳机; 5.勿将耳机放入火炉或使用高于5V的充电电压; 6.不要让3岁以下儿童使用, 内包含小零件; 7.请勿将其丢弃于生活垃圾, 如想丢弃请将其送至当地的电器设备回收站; 注意:若用户因违反以上警告内容造成的人身财产损失,本公司不承担责任。</p>	<p>FCC Radiation Exposure Statement The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.</p> <p>RockShine</p> <p>R1</p>