

MLP-T06

说明书成品尺寸：73X80mm128铜版纸覆哑膜钢琴 折

MLP-T06  
小马宝莉小豆包入耳式蓝牙耳机  
使用说明书

包装清单

产品示意图

产品参数

功能	描述
蓝牙版本	V5.3
传输距离	10m
额定输入	5V=300mA
充电时间	约2h
音乐时间	约4-5h
耳机电池容量	30mAh*2
充电仓电池容量	180mAh
充电接口	USB-C
防水等级	IPX4
频率	2.400GHz

注意事项

1. 请将此产品放置在儿童无法接触的地方。

2. 请在温度 5℃-35℃ 范围内使用及存放产品及配件，当环境温度过高或过低时，可能会引起故障。

3. 请合理控制使用耳机的音量和时间，以免损伤听力。

4. 请勿在驾车、骑自行车、操作机器或者从事需要注意外界声音的工作时间使用产品。

5. 请勿将产品拆解、撞击、挤压或投入火中，以免发生爆炸。

若电池出现膨胀、漏液请勿继续使用。

6. 请勿在雷暴天气下使用设备，雷暴可导致设备工作异常并增加触电的危险。

7. 在使用本设备时，请与植入的医疗设备(如起搏器等)保持至少 15 厘米的距离。

8. 由于蓝牙技术的特性，信号的强弱与具体使用环境有关，如果附近有较多无线信号重叠或者有较强电磁波干扰,蓝牙耳机接收到的信号变弱，甚至断连。

9. 如果长期不使用，请每三个月给产品充电一次,避免电池过放损坏。

10. 清洁、维护设备前停止使用设备，请使用清洁、干燥的软布擦拭设备。

11. 推荐使用品牌厂商，通过 CCC 认证，输出电压为 5V 的充电器给本产品充电。

请避免使用输出电压超过 5V 的快速充电器，以免因高电压充电损坏产品!

充电仓指示说明（只做参考，以实物为准）

产品状态	指示灯显示
充电仓充电状态	红灯闪烁
充电仓充满电 耳机充电状态	红灯常亮
充电仓充满电 耳机充满电状态	红灯熄灭
给耳机充电 充电仓状态	蓝灯常亮
耳机充满电 充电仓状态	蓝灯熄灭
充电仓低电状态	充电仓电量≤15%，蓝灯快闪至熄灭

功能键操作

■ 语音助手

苹果系统：唤醒 "siri"  
长按左耳功能键2S启动/关闭语音助手

安卓系统：支持唤醒语音助手  
长按左耳功能键2S启动/关闭语音助手

■ 通话模式

接听/挂断来电：双击左/右功能键  
指示灯熄灭

来电拒接：长按左/右耳触摸键2S拒接来电  
指示灯熄灭  
无报号/耳机内无同步手机铃声（手机响铃声）

■ 音乐模式

播放/暂停：音乐状态下，双击左/右功能键  
指示灯熄灭

上一曲：三击左耳功能键，切换至上一曲并播放  
指示灯熄灭

下一曲：三击右耳功能键，切换至下一曲并播放  
指示灯熄灭

■ 普通模式

音量+：单击右功能键音量+，最大提示音  
提示音“咚咚”

音量-：单击左功能键音量-

功能键操作

■ 音乐/游戏模式

游戏模式：长按右耳触摸键2S

音乐模式（开机默认）：长按右耳触摸键2S

■ 耳机充电

耳机放入充电仓并关仓开始充电：耳机红灯长亮

耳机充满电：耳机在充电盒中，耳机红灯熄灭

■ 耳机电量提示

开机状态：提示音（每1分钟一次）5次后关机  
耳机红灯快闪

连接设备成功：MLP-T06

产品中有害物质名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T11364的规定编制  
O表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定限量要求以下。  
X表示该有害物质至少在该部件的某一均质材料中的含量超出GB26572规定的限量要求。  
表中标记“X”的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。

本表格依据SJ/T11364的规定编制  
印刷电路组件\*包括印刷电路板及其零部件、电子元器件等。  
根据产品型号不同,您所购买的产品可能不会含有以上所有部件。

指不含有6种有毒有害物质或含有但小于限量值，字母“e”代表英文字母电子(electronic);电子(electrical)和环境(environment)的首字母；环绕的曲线箭头表示可回收利用。

保修声明

免责声明  
本使用手册没有任何形式的担保、立场表达或其他暗示。本使用手册所提到的产品、规格及信息仅供参考，内容亦会随时更新于网页，恕不另行通知。

保修声明：  
就本产品：购买本产品时，本产品自购买之日起十二(12)个月(“保修期”)内，在正常使用情况下因质量问题发生损坏，能修理的，免费修理；经厂家确认无法修理的，免费更换、修理或更换后的产品。在剩余保修期（最短不少于30天）内继续享有保修。购买日以销售发票日期为准，如无法确定购买日，则保修期自产品生产日期起按十三(13)个月计算。

如申请保修，请先致电产品服务热线，并按我们指示的方式执行。申请保修时，您需要提供准确、完整和清晰填写的有效销售发票。以上保证不适用于下列情况：  
1. 超过三包有效期的；  
2. 涂改保修卡、产品编号与产品本体不符；  
3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏；  
4. 因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏；  
5. 因碰撞、弯曲或压力过大而损坏；  
6. 因负载过重造成的线路或断裂；  
7. 任何因尖锐物体造成的损坏；  
8. 因接触腐蚀性液体或水而造成的损坏；  
9. 因私自拆卸或改装导致的损坏；  
10. 产品在正常使用过程中发生的老化、褪色、磨损、破裂和其他损耗。  
11. 如产品原有标识标准被篡改或损毁，本保证将失效。

以上保证是我们就产品做出的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权益。

服务热线: 400-885-8808

温馨提示

1. 除说明书有特殊标示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。

2. 请勿将产品放入水或其他任何液体中，此产品非防水设计。

3. 如果有任何液体不小心进入产品内部时，请立即断开连接并移开此产品。

4. 为避免触电，请在安装或卸载产品时，确保手上没有沾水。

5. 请勿将此产品放置于热源附近或直接暴露在火源附近。

6. 请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。

合格证

产品编号: \_\_\_\_\_  
生产日期: \_\_\_\_\_  
检验员: \_\_\_\_\_

MLP-T06  
My Little Pony Little Cuties  
In-ear BT Headset instruction manual

Packing list

产品示意图

Product specifications

Function	Description
BT version	V5.3
Transmission distance	10m
Rated inputs	5V=300mA
Charging time	About 2h
Music time	About 4-5h
Headset battery capacity	30mAh*2
Charging compartment battery capacity	180mAh
Charging port	USB-C
Waterproof level	IPX4
Frequency	2.400GHz

Precautions

1. Please keep this product out of reach of children.

2. Please use and store the products and accessories within the temperature range of 5°C-35°C, when the ambient temperature is too high or too low, May cause malfunction.

3. Please control the volume and time of using the headphones reasonably to avoid hearing damage.

4. Do not use the product while driving, riding a bicycle, operating a machine, or during working hours that require attention to outside sounds

5. Do not disassemble, impact, squeeze or throw the product into the fire to avoid explosion.If the battery is swollen or leaking, do not continue to use it.

6. Do not use the device in thunderstorm weather, thunderstorms can cause the device to work abnormally and increase the risk of electric shock.

7. When using this device, keep a distance of at least 15 cm from the implanted medical device (e.g., pacemaker, etc.).

8. Due to the characteristics of Bluetooth technology, the strength of the signal is related to the specific use environment, if there are more wireless signals nearby Overlapping or strong electromagnetic interference, the signal received by the BT headset becomes weaker or even disconnected.

9. If it is not used for a long time, please charge the product every three months to avoid damage to the battery due to over-discharge.

10. Stop using the device before cleaning and maintaining the equipment, and use a clean, dry soft cloth to wipe the equipment

11. It is recommended to use a charger from a brand manufacturer, CCC certified, and an output voltage of 5V to charge this product.

Please avoid using a fast charger with an output voltage of more than 5V to avoid over charging at too high voltage and damaging the product!

Instructions for charging compartment  
(for reference only, subject to the actual product)

Product status	Indicator light display
Charging status of the charging case	The red light flashes
The charging case is fully charged Charging status of the earbuds	The red light is always on
The charging case is fully charged The headphones are fully charged	The red light goes out
Charge the headphones The status of the charging case	The blue light is always on
The headphones are fully charged The status of the charging case	The blue light goes out
The charging compartment is in a low state of power	The charging compartment is <15% of the battery, and the blue light flashes quickly until it turns off

Function key operation

■ Voice assistant

Apple system: Wake up "siri"  
Long press the left ear function button for 2S to start/turn off the voice assistant

Android: Support woke-up voice assistant  
Long press the left ear function button for 2S to start/turn off the voice assistant  
Answer/Hang Up an Incoming Call: Double-click the left/right function key  
The indicator light is off

■ Call mode

Call rejection: Long press the left/right ear touch button for 2S to reject the call  
The indicator light is off. No announcer number/no synchronized mobile phone ring-tone in the earphone (mobile phone ringtone)

Play/Pause: In the music state, double-click the left/right function keys. The indicator light is off

Previous track: Triple tap the function button of the left ear to switch to the previous song and play

Next track: Triple tap the right ear function button to switch to the next song and play

■ Music mode

Volume ++: Click the right function key Volume ++ to make the maximum prompt sound.  
Prompt sound "Knock Knock"

Volume --: Click on the left function key

Function key operation

■ Call mode

Game mode: Long press the touch button on the right ear for 2S

Music mode (default when powered on): Press and hold the touch button on the right ear for 2S

■ Music mode

Put the earbuds into the charging compartment and close the compartment to start charging: the earbuds will be red and on

The earbuds are fully charged: The earbuds are in the charging case, and the red light of the earbuds is off

■ Normal mode

Power on status: Prompt tone (once every 1 minute) 5 times and then power off  
The headphones flash red light

连接设备成功：MLP-T06

Names And Contents Of Hazardous Substances In Products

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.  
O indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.  
X indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.  
The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:  
Including printed circuit boards and their parts, electronic components, etc. and depending on the product model, the earbuds you purchased may not contain all of the above components.

Refers to not containing 6 toxic and harmful substances or containing but less than the limit value, with the letter "e" representing the English letter "electronic"; The first letters of electronic and environmental;  
The curved arrows surrounding indicate recyclability.

Warranty Statement

Disclaimer  
This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only and the content will also be updated on the web at any time without additional separate notice

Warranty statement:  
The product attached to this document is guaranteed as follows: If the product is within the warranty period (the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired. Free repair/replace/replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale the ticket date shall prevail. If the purchase date cannot be determined, the warranty period shall be 15 (15) months.  
If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:  
1. Exceeding the validity period of the three packs;  
2. Altering the warranty card and product code does not match the product body;  
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage obstacles or damage;  
4. Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident;  
5. The zipper and tower buckle are damaged due to excessive force;  
6. Products with signs of burning or flooding;  
7. Damage caused by unauthorized disassembly;  
8. Products with signs of burning or flooding;  
9. Damage caused by unauthorized disassembly;  
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;  
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

Warranty Statement

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law.

E-mail: service@keesoon.com

Tips

1. Do not attempt to disassemble or replace any parts of the product except for those operations specifically indicated in the instruction manual.

2. Do not put the product into water or any other liquid, this product is not designed to be waterproof.

3. If any liquid accidentally enters the product, disconnect and remove the product immediately.

4. To avoid electric shock, make sure there is no water on your hands when installing or uninstalling the product.

5. Do not place this product near a heat source or expose it directly to a source of ignition.

6. Do not place this product in an environment with strong electromagnetic forces, as this may cause the product to malfunction.

Certificate of Approval

Product No.: \_\_\_\_\_  
Production Time: \_\_\_\_\_

**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.