
TRANSFORMERS



TF-T51真无线蓝牙耳机 使用说明书

充电仓X1 说明书&保修卡X1 Type-C充电线X1 产品示意图

温馨提示

- 1.切勿使用具有磨蚀性的清洁剂清理本产品。
- 2.切勿让本产品加热或靠近火源,如煮食炉。 3.切勿让本产品长时间受阳光直接照射。
- 4.切勿将本产品弃置于火中,避免发生爆炸。
- 5.切勿尝试拆开本产品作出任何修改,因为它并不包含任何维修组件。
- 6.切勿在雨山使田木产品 7.如果长时期内不打算使用本产品,请您将它储存在干燥的环境中,
- 并每月至少为耳机充电一次以延长寿命,避免极端的温度和灰尘。

产品规格

蓝牙版本: V5.4 传输距离·>10米 音乐时间:约4小时 喇叭尺寸: Φ13mm 充电时间·约15小时 电池容量: 30mAh 额定输λ·5V==30mA

充电仓规格

电池容量: 300mAh 充电时间:约2小时 额定输入·5V==300mA (所有技术信息以实际性能为准)

给充由仓充由田

Type-C充电线连接充电仓到5V电源适配器。 (温馨提示: 耳机电池电量低于3.3V 开始播报低电提醒(声音提示: battery low), 红灯慢闪 每1分钟提醒—次请及时给百机充由)



额定输入: 5V==30mA (耳机) 额定输入: 5V==300mA (充电仓)

LED指示状态

红灯长亮1秒熄灭 TWS配对状态 红白灯交替闪烁 主耳红白灯交替闪烁, 副耳熄灭

充电仓指示说明(只做参考, 以实物为准)

充电仓充电状态	电量显示末位数字闪烁
充电仓充满电状态	电量显示常亮
给耳机充电,充电仓状态	电量显示常亮
耳机充满电充电仓状态	数显熄灭
充电仓低电状态	电量显示末位数字闪烁至熄灭

产品操作说明

方法一: 从充电仓取出耳机, 耳机开机 方法二: 长按左右耳机触摸区域3秒, 耳机开机

方法一: 放回充电仓, 耳机自动关机 方法二: 耳机在3分钟内没有连接设备自动关机 (关机提示音: "power off")

步骤一: 开机后.左右耳机自动互连后进入与手机配对状态(提示音: "pairing") 步骤二、打开智能设备的蓝牙列表,搜索"TF-T51"并连接 温馨提示: 左右耳机出现不配对时,请恢复出厂设置,放回充电盒再打开自动配对

■ 常规模式



_______ 音量 --单击左耳机 Touch 键(最小提示音"咚咚")









恢复出厂设置

方法の开机未连接状态:连击左/右耳机5次后红灯长亮1秒熄灭清除配对信息左/右耳机关机: 方法②开机连接状态: 左/右耳机连击5次, 听到"咚"声后, 3秒内长按10秒熄灭清除耳机与 蓝牙设备之间的配对信息后关机

The white light is on for 1 second

Shut down The red light turns off for 1 second

Headphone charging The red light is on
The headphones are fully charged The red light is out
Restore factory settings The red light turns off for 1 second

TWS pairing status Red and white lights flashing alternately
Disconnecting from The red and white lights of the main par flash alternately, and the secondary eros are turned of the secondary eros are turned of the secondary expenses.

产品中有害物质的名称及含量

部件名称	有害物质						
	铅 Pb	汞 Hg	镉 Cd	六价铬 Cr(VI)	多溴联苯 PBB	多溴二苯醚 PBDE	
印刷电路板组件	0	0	0	0	0	0	
外壳等小结构件	0	0	0	0	0	0	

本表格依据SJ/T 11364的规定编制。

-):表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下
- 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。 主: 1. 表中标记"×"的部件,皆因全球技术发展水平限制而无法实现有害物质的替代;
- 2 印刷由路板组件、包括印刷由路板及其零部件 由子元器件等。 3. 根据产品型号不同,您所购买的产品可能不会含有以上所有部件。



FC CE & D EA CH



保修声明

本使用手册没有任何形式的担保、立场表达或其他暗示。本使用手册所提到的产品、规格

及信息仅供参考、内容亦会随时更新于网页、恕不另行通知。 就本文件附随的产品做如下保证: 如产品在您购买日起十二 (12) 个月 ("保修期") 内,

- 在正常使用情况下因质量瑕疵发生损坏,能修理的,免费修理;经厂家确认无法修理的, 免费更换: 修理或更换后的产品。在剩余保修期(最短不少干30天)内继续享有保修。购 买日以销售发票日期为准,如无法确定购买日,则保修期自产品生产日期起按十三(13) 个月计算。如申请保修,请先致电产品服务热线,并按我们指示的方式执行。申请保修
- 时 您需要提供准确 完整和清晰填写的有效销售发票。

以上保证不适用于下列情况: 1. 超过三包有效期的;

- 2 涂改保修卡 产品编码与产品本体不符:
- 3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
- 4. 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏; 5. 拉链、塔扣因受力过大而损坏;
- 4 田承恭讨香造成的的线动斯烈。
- 7. 任何因尖锐物体造成的损坏: 8. 有烧损或水浸迹象的产品;
- 9 因擅自抵改异致的损坏:
- 10. 产品下常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。 11. 如产品原有标识标签被更改或损毁、本保证将失效。

产品及随附物料的齐备和外观完好不属于保证范围。您应在接收产品时当场检验并对任何

以上保证是我们就产品做出的全部保证,且仅在中国大陆地区境内适用。本文件的任何内 容均不影响根据法律规定不能排除或限制的消费者权利。

服务监督热线: 400-885-8808

TRANSFORMERS

用户姓名 电子邮件 联系电话 邮政编码 通讯地址 产品型목 产品名称 产品条码/编号/批号 名 称 联系电话 邮政编码 销售日期 发票号码

尊敬的用户,本保修卡是您将来申请保修的凭证,请您配合销售商填写并妥善保管备用!




Warranty Service Dear user, this warranty card is the proof of your future warranty application, please cooperatewith the seller to fill it out and keep it for future use! Postal code

Product number


Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
D	· · · · · · · · · · · · · · · · · · ·

Certificate of Approval Product No: Production Time: QC:

TRANSFORMERS



headphones Instruction manual




TF-T51 True wireless BT

Product specifications

BT version: V5.4 Horn size: @13mm headset X2 Charging CaseX1 Instructions Type-C Charging Warranty cardX1 CableX1

Product diagram



TRANSFORMERS

- 1. Do not use abrasive cleaner to clean this product.
- 2. Do not let this product be heated or close to the fire source, such as a cooking stove.
- 3. Do not let this product be directly exposed to sunlight for a long time. 4. Do not discard this product in the fire to avoid explosion. 5. Do not try to open this product to make any changes, because it does
- not contain any repair components. 6. Do not use this product in the rain.
- 7. If you do not plan to use this product for a long time, please store it in a dry environment and charge the headphones at least once a month to extend their life and avoid extreme temperatures and dust.

Transmission distance: ≥ 10M Music time: about 4 hours Charging time: about 1.5 hours Battery capacity: 30mAh Rated input: 5V === 30mA

Charging case specifications

Battery capacity: 300mAh

Charging time: about 2 hours Rated input: 5V == 300mA (All technical information is subject to actual performance)

To charge the charging box The Type-C charging cable connects the charging bay to the 5V power adapter. (Warm tip: When the headset battery is less than 3.3V, it will broadcast a reminder of low battery (voice prompt; battery low). The red light flashes slowly, reminding once every minute. Please charge the earphone in time.



Instructions for charging compartment

LED indicates the status

Charging status of charging bin	The last digit of the power display flashes
The charging compartment is fully charged	The power is always on
Charge the headphones, the status of the charging compartment	The power is always on
The status of the fully charged charging compartment of the headphones	Digital display is extinguished
Low power state of the charging compartment	The last digit of the charge display flashes until it is turned off

Product Operation Instructions

@Shutdown Method 1: PLt.it back in the charging bay, and the headset automatically shuts off Method 2: If the headset is not connected within 3 minutes, the device will automatically into Month (Shutdown prompt tone: "power off")

©Poining

Step 1. After the device is started, the left and right earphones are automatically connected and enter the pairing state with mobile phones (prompt tone: "Pairing").

Step 2. Open the BT list of the smart device, search for "FT-O" and connect.

Tips: If the left and right earphones do not match, please restore the factory Settings, put them back in the charging box and turn on the automatic pairing.















Answer the call: double-click the left/right headphone Touch button
End the call: Double-click the left/right headphone Touch button
Reject the call: Long press the left/right headphone Touch key 2S



Long press the Touch button of the left headset for 2 seconds to start/furn off the voice assistant

Long press the right headphone Touch key 2S to switch game/music mode

Method 1 Unconnected state: After 5 consecutive clicks on the left/right headphones, the red lighturns on for 1 second to turn off, clear the pairing information, turn off the left/right headphones;

The name and content of harmful substances in the product

Part name	Harmful substances						
Part name	Pb	Hg	Cd	Cr(VI)	PBB	PBDE	
Printed circuit board components	0	0	0	0	0	0	
Small structural parts such as shell	0	0	0	0	0	0	

This form is compiled in accordance with the provisions of SJ/T 11364. O: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572. s: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified

GB/T 26572. Note: 1. The parts marked with "x" on the table are unable to achieve the replacement of harmful substances due to limitations in alobal technological development:

2. Printed circuit board components: including printed circuit boards and their parts, electronic components, etc: 3. Depending on the product model, the product you purchased may not

Electronic and electrical products sold in the People's Republic of China must mark this logo, the number in the logo represents the product under normal use















within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.

Discurine:

This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without

The above guarantee does not apply to the following situations:

1. Exceeding the validity period of three guarantees;

2. Altering the warranty card, the product code does not match the product body;

3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance

storage; Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or

accidents; 5. Zipper and tower buckle are damaged due to excessive force;

Service supervision hotline: 400-885-8808

虚线做 易撕线

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

ISED Statement

- English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- French:Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux CNR exempts de licence d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :
- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé.

Cet équipement doit être installé et utilisé avec une distance minimale de 0 cm entre le radiateur et votre corps.