

# 157g哑粉纸 对折后尺寸90\*65mm 正反印

**AI Voice Assistant**


Model: AI-S1

Before Use: Ensure the device is connected to a Wi-Fi network and activated.  
Wake Word: "Hello, baby"

Product Specifications	
Battery	800mAh / 3.7V
Power Supply	DC-5V
Speaker	3W/4Ω
Dimensions	117*74.8*49.9mm
AI Model	Deepseek/Douba (TikTok)
Network	Wi-Fi 2.4G
Overall Battery Life	3 hours
Volume Control	Voice Control
Net Weight	100g
Operating Temperature	-10°C to 60°C





**USER NETWORK CONFIGURATION**


1.Press and hold the function button for 3 seconds until you hear the voice prompt: "Enter the Wi-Fi configuration mode."  
2.Connect your smartphone to the AI Voice Assistant's hotspot named "xiaozi-xxxx". Once connected, the Wi-Fi configuration page will appear automatically.  
3.Customize Settings:In the Character Settings interface, you can choose the voice style and AI model.  
4.Select a Wi-Fi network:From the list, choose your home Wi-Fi, enter the password, and tap Connect. After a successful connection, the device will automatically exit setup after a 3-second countdown.  
5.Re-enter Configuration:To reconfigure the network later, press and hold the function button for 3 seconds again to reconnect to "xiaozi-xxxx".



**BUTTON FUNCTIONS**


1.Light Button: Cycle through modes with a single press, or use voice interaction to control the device.  
Mode 1: Default Indicator Light Mode. Blue light: Indicates the AI Voice Assistant is responding.  
Green light: Indicates the user is speaking or asking a question.  
Mode 2: Night light mode.  
Mode 3: Colorful ambient mode.  
Mode 4: light off.  
2.Function Button: Interrupt Conversation: Press once to interrupt and ask a new question.  
Network Configuration: Long press for 3 seconds to enter network configuration mode.  
Follow the user manual instructions to complete setup.  
**Note:** First-time use requires long-press for network setup. Device operation depends on successful network connection.

Function Button	
 01 Default Indicator Light Mode	 01 Press once to interrupt and ask a new question.
 02 Night Light Mode.	 02 Press and hold for 3 seconds to enter network configuration mode.
 03 Colorful Ambient Mode	



90 mm

65 mm



90 mm

90 mm

90 mm

90 mm

正面

背面

2025.7.30

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.