
ITL-304D Remote control operation instruction



As shown in the figure:

- 1, 1 button: to turn light ON or OFF.
- 2 button: Press the button for more than 0.7 seconds to start adjusting the brightness of the light, cycling between maximum and minimum brightness. The lights cycle every eight seconds.
- 3、3 button: to turn fan ON or OFF.
- 4、4 button: to set the fan speed to high.
- 5 \ 5 button: to set the fan speed to medium.
- 6. 6 button: to set the fan speed to low.
- 7, LED indicator: Press any key of the remote control, the indicator light will light up, and the remote control will issue instructions.

Remote control pairing: Within 30 seconds after power is restored to the controller, press and hold the "3" key on the remote control transmitter for 5 seconds or until the light on the fan flashes. Test the light and fan functions using the remote transmitter to confirm that the learning process is complete.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.