






<div data-bbox="278 483 589 671"></div> <div data-bbox="299 799 562 884"><p>CHARGING MOUSE PAD</p><p>User Manual</p></div>	<div data-bbox="716 426 889 445"><p>Operation Instruction:</p></div> <div data-bbox="716 461 1064 652"><p>1. Using a cable to connect an adapter or computer, you can start to charge</p><p>2. Just put your smartphone on the device directly without cable</p><p>3. Confirm your smartphone is built-in or insert a wireless receiver before charging</p><p>4. You can take your phone away for calling or place it back for charging freely</p></div> <div data-bbox="722 657 1067 879"></div> <div data-bbox="734 898 1031 938"><p>Connect the adapter and the wireless charger with USB cable</p></div>	<div data-bbox="1206 432 1512 592"></div> <div data-bbox="1176 627 1496 667"><p>Just put your smartphone on the wireless charger when charging</p></div> <div data-bbox="1146 722 1527 882"></div> <div data-bbox="1257 914 1412 932"><p>Connect with computer</p></div>	<div data-bbox="1623 426 1971 474"><p>Suitable for smart phones:</p><p>Apple: iPhone 14 Pro,iPhone 14,iPhone 13,iPhone 12</p></div> <div data-bbox="1623 504 1850 671"><p>Specification:</p><p>Product: CHARGING MOUSE PAD</p><p>Model No: 32H3GELN1V</p><p>Input: 5/3A,9V/2A,12/1.67A</p><p>Output: 15W</p><p>Working Temperature: -10℃—55℃</p><p>Charging distance: 0-8mm</p></div> <div data-bbox="1623 702 1835 791"><p>Accessories:</p><p>Mouse pad Wireless charger 1 pc</p><p>USB cable 1 pc</p><p>User manual 1 pc</p></div> <div data-bbox="1623 850 1971 932"><div></div><p>Made in China</p></div>	<div data-bbox="2077 426 2153 445"><p>Attention:</p></div> <div data-bbox="2077 461 2425 740"><p>1. The wireless charger has no interference on all housedhold appliances</p><p>2. Do not place any magnetic card like bank card or ID card near the product to prevent magnet failing to work</p><p>3. As usual, it does not need any maintenance. The power is in sleep mode automatically if the charge stops. Keep the surface clean from dust or metal.</p><p>4. If the wireless charger cannot work normally, or other interference. please move the interference device away. Replace the USB cable or adapter for use again.</p></div>	<div data-bbox="2494 383 2896 973"><p>FCC Warning</p><p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p><p>(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p><p>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p><p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p><p>-Reorient or relocate the receiving antenna.</p><p>-Increase the separation between the equipment and receiver.</p><p>-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p><p>-Consult the dealer or an experienced radio/TV technician for help.</p><p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p></div>
--	--	--	--	--	--

尺寸:60x80mm

材质:128g双铜 苹果白