


User Manual

(Model: BL01)



Thank you for purchasing our products.

Please read this manual carefully before use and retain it for future reference.

EN 01

Connecting the Device

Connect the included AC adapter to the DC jack located on the back of the clock and connect the other end to a 100V~ 220V wall outlet.

Battery Backup


The product needs to be plugged in for operation. There is a battery compartment at the bottom of the product, which can hold one CR2032 backup battery to save clock settings in the event of a temporary power failure.

Product Preservation

Place the product on a level surface away from sources of direct sunlight or excessive heat or moisture.


Product Cleaning

Wipe clean with a soft damp cloth. Strong clean agents can cause damage to the surface of the item.



EN 03

Know Your PowerGlow



- | | | | |
|----------------------------------|-----------------------------|-------------------------------|-------------------------|
| 2. Bluetooth pairing | 7. Color-changing light | 13. Battery compartment | 19. Alarm 1 mode switch |
| 3. Sleep mode | 8. Solid single color light | 14. Display brightness dimmer | 20. Time format |
| 4. Play/Pause handfree phonecall | 9. Timer | 15. Volume | 21. DC jack |
| 5. Down/Previous track | 10. Microphone | 16. Alarm 1 | 22. Speakers |
| 6. Up/Next track | 11. Snooze | 17. Alarm 2 | 23. USB port |
| | 12. Display | 18. Alarm 2 mode switch | |


EN 02

1. Press and hold the Time Button until the display flashes.
2. Press the \rightarrow / \leftarrow / \rightarrow / \leftarrow Buttons to adjust selections and tap Time Button to confirm (make sure you set the correct AM/PM time).
3. Repeat this for year, month, and date setting.

PowerGlow features dual alarms which can be set to different times and alarm sources. Each alarm is set in the same way. Use M / W Buttons to set respective alarms. Note: Each step must be completed while the display is flashing or the setting will time-out with any changes saved.

Select alarm mode

There are two switches located on the back corresponding to each alarm. You can switch between three modes to make your alarms work on everyday, weekdays or weekends: Mon-Sun, Mon-Fri, Sat-Sun.



Dimmer

Rotate the Display knob on the back to adjust the brightness of the display from 0 to 100%.

EN 05

-
1. Press and hold the Alarm Button for 2 seconds until the alarm time display and alarm icon flash.
 2. Press **First/Last** **Next/Previous** the Buttons to adjust the alarm time(hold for rapid setting). Make sure you set the correct AM/PM alarm time. The AM/PM indicator appears to the upper left of the display.
 3. Click Alarm Button to confirm the alarm time setting. The alarm tone will sound.
 4. Press **First/Last** **Next/Previous** to select a desired wakeup tone from 7 options, and press the Alarm Button to confirm the selection. The alarm volume will flash.
 5. Press **First/Last** **Next/Previous** to select a desired volume level(Level 1-Level 15). Press the Alarm Button to confirm alarm volume and exit alarm setting mode. The alarm icon will remain on the display, to show the alarm is enabled.

Snooze

When the alarm is going off, tap the **SNOOZE** bar to snooze for 9 minutes. You can snooze the alarm unlimited times. The Zzz icon will appear on the display when Snooze is active.

Stop the alarm

Press any physical button on the clock when the alarm is sounding will stop the alarm for the day without disabling the alarm for the next day.

When the alarm goes off continuously for 30 minutes without any operation, the alarm will automatically stop and the alarm for the next day will not be affected.

EN 06

1. Color changing mode

- Press the Button repeatedly to cycle through the 6 colorful lighting options.
- Short press the button to adjust the light brightness between L01 to L10.
- Press and hold the Button for 2 seconds to turn off the Color-changing mode and the icon will disappear from the display.

2.Solid single color mode

- Press the Button repeatedly to cycle through the 8 Solid single color lighting options.
- Short press the button to adjust the light brightness between L01 to L10.
- Press and hold the Button for 2 seconds to turn off the Solid single color mode and the icon will disappear from the display.

- Short press the Button to turn on the Sleep Timer, and the icon will display. Press the Button again to select a desired duration from 15min/30min/60min/90min/120min. Default setting is 30min.
- Press and hold the Button for 2 seconds to exit the Sleep Timer mode.
- After the time period elapses, the lights and sound will turn off automatically.
- Press the Button to check the remaining time.
- PowerGlow remembers and keeps your last setting (sleep sound, lights and timer) when you turn it on next time.

EN 08

1. Bluetooth pairing

- Short press the BT button on the top of the item.
- Turn on Bluetooth on your device and select “BL01” on the Bluetooth menu to connect.
- Once paired successfully, a voice prompt will be heard and Bluetooth indicator will appear on the upper left corner of the display, indicating the PowerGlow is ready to stream audio from your device.
- If no device is paired within 5 minutes, PowerGlow will automatically exit the Bluetooth mode and the Bluetooth icon will disappear.

2. Playing audio

1. Press the Button to play/pause music or answer/hang up phone call.
3. Press and hold the **First/Last** Button for 2 seconds to play the previous track.
4. Press and hold the **Next/Previous** Button for 2 seconds to play the next track.
5. Rotate the Volume knob on the back to adjust the volume.


3. Turn off Bluetooth

- In Bluetooth mode, press and hold the BT Button for 2 seconds to turn Bluetooth off, and the Bluetooth icon will disappear.

- Press the Button repeatedly to cycle through 10 different soothing sounds.
- Rotate the Volume knob on the back to adjust the volume.
- Press the Button to pause the sound; press and hold the Button for 2 seconds to turn off the Sleep Mode.

EN 07

- Unscrew the cover of the battery compartment.
- Remove the old and replace with a new CR2032 battery.
- Screw the cover back on.



WARNING

- Do not ingest the battery, Chemical Burn Hazard. This product contains a button cell battery. If the button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.”
- Attention should be drawn to the environmental aspects of battery disposal.

EN 09

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.