

Address: 207A 2/F, C Building, Banwei Industrial Zone, YongXiang Road, Longgang District, Shenzhen City, China.

[www.anthenelec.com](http://www.anthenelec.com)



## INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND REMAIN FOR FUTURE USE

### Packing included:

1. Wireless speaker-----1PCS
2. Charging cable-----1PCS
3. User manual-----1PCS

### Button Overview



#### Power on/Off/Mode

1. Long press to turn on/off the device
2. Click it to change the BT mode and white noise mode and clock



#### Timer Setting

1. Short press into time setting. Short press  and  to adjust the time. After finish the setting, short press  to confirm the setting.



#### Volume Up

1. Bluetooth mode , long press to increase the volume
2. Setting Alarm clock, single press to adjust the time.



#### Track Next

1. Bluetooth mode, single click to the next song
2. In white noise mode, single click to next sound



#### Play/Pause/LED Switch /LED Mode/BT

1. In Bluetooth mode/white noise sound mode, single click to Play/pause the music/sound
2. Long press to change the LED mode ( sleeping LED mode, rhythm LED mode, colorful LED mode)
3. Dual click to turn on/off the LED light
4. Click three times to disconnect the BT pairing



#### Track Prev.

1. Bluetooth mode, single click to the previous song
2. In white noise mode, single click to previous sound



## Volume Down

1. Bluetooth mode, long press to decrease the volume
2. Setting Alarm clock, single press to adjust the time.



## White Noise Time Setting

In white noise mode, single press to change the white noise time among 30-60-90seconds.



## Alarm Clock Setting

1. Click this button to setup the alarm clock,
2. Short press to change the alarm clock sound
3. Short press to turn off/on the alarm clock
4. Long press to turn off the prompt voice.



## Type-C/ DC5V Charging

Connect the charging cable to speaker's Type-C port, insert the other end to a adapter in 5V (not include). A red light is on when charging, and will switch off when full charge is reached.

### Bluetooth Connection

Use cell phone or other device search Bluetooth pairing name RS11 to connect, and the prompt voice will remind the Bluetooth connected successfully.

### Time Setting

Single click enter into timer setting, The Hour digit will flash, short press and to change Hour time (AM/PM icon will light up). Press again to confirm the Hour time, and Minute digit will flash, short press and to adjust the Minute time and time setting done, press to save the setting.

### Alarm Clock Setting

Single click enter into alarm clock setting. Short Press and to adjust the Hour time (AM/PM icon will light up), press to confirm the Hour time. And minute digit will flash, short press and to adjust the minute time, after setting done, press to confirm the time setting, and enter into setting the alarm sound use and to choose the music. After choose the music, press again to save the alarm clock setting. And alarm clock icon will light up.

Press or to turn on / off the alarm clock.

Press to close the alarm ringing.

## Technical Specification on

Wireless Version	V5.3
Input	5V/1A
Output Power	5W*1
Maximum Working Range	10 M
Music Playing Time	3-4Hours
Battery Type	1000mAh
Product Size	10.5*10.5*6.5CM
Accessories	1* Type-C charging cable 1* User Manual

### FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may

cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.