


 <p>Manual HUHUVE <small>Works with Apple Find My</small></p> 	<p>Important tips: When pairing a device with Find My® app, the phone will link to the Apple® Server. Pairing may fail because of network problems. The following actions are recommended: Change the phone's network, such as switching between WiFi and mobile network.</p> <p>01. Turn on the device</p> <p>Press and hold the button for 3 seconds, and the device will beep and turn on. Double press the button. A chime will sound. Note: To turn off, double-click the device first, then quickly press the button 5 times within 2 seconds, a long beep will sound.</p> 	<p>02. Pair the device</p> 	<p>03. Locate Your</p> <p>03.1 Find H-001 When It's Nearby: Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your H-001 from the list. Tap "Play Sound" to make your H-001 beep. Tap "Stop Sound" to stop the beeps once you find.</p> <p>03.2 Find H-001's Location: Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your H-001 from the list. Your H-001's location will appear on the Map with a time stamp of when the item was located. To navigate to the H-001's location, tap "Directions" to open Apple Maps.</p> <p>04. Notifications</p> <p>04.1 Enabling "Notify When Left Behind": Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your H-001 from the list. Under "Notifications" enable the "Notify When Left Behind" toggle. You will receive a notification when you leave your H-001 behind and it's no longer in range of your device.</p>	<p>04.2 Enabling "Notify When Found": Under "Notifications", enable the "Notify When Found" toggle. When your H-001 is seen by another Find My network device, you will receive a notification of its location. Note: "Notify When Found" can only be activated when your H-001 is out of range.</p> <p>05. When Your H-001 Is Lost</p> <p>05.1 Enabling "Lost Mode": Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your H-001 from the list. Under "Lost Mode" tap "Enable". A screen detailing Lost Mode will pop up, tap "Continue" Enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode". Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled. Note: When "Lost Mode" is enabled, your H-001 is locked and cannot be paired to a new device.</p>
<p>06. Resetting H-001</p> <p>06.1 Remove The H-001 From Find My App: Open Find My app and select the "Items" tab. Tap on your H-001 from the list. Please ensure "Lost Mode" is disabled. Scroll to the bottom of the screen and tap "Remove Item". A summary will open, tap "Remove" to confirm.</p> <p>06.2 Connect Your H-001 After successfully removing the H-001 from Find My app, quickly press the device twice. A chime will sound, then, Press and hold the button for about 5 seconds, after the second confirmation chime sound. Press and Hold again for another 3 seconds until you hear a prompt sound to reset the device. The H-001 is now reset and ready to be paired to a new Apple ID.</p>	<p>07. Extras</p> <p>07.1 Unwanted tracking: If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways: 1. If you have an iPhone, iPad®, Find My will send a notification to your Apple device. This feature is available on iOS or iPad OS 14.5 or later. 2. If you don't have an iOS device or a smartphone, a Find My network accessory that is n't with its owner for a period of time will emit a sound when it's moved.</p> <p>08. About Apple Find My The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac®, or the Find Items app on Apple Watch.</p> <p>All Apple phone system versions must be at least 14.3, according to Apple's official requirements, otherwise the phone cannot connect to the device.</p>	<p>09. The Fine Print</p> <p>FCC WARNING</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. <p>Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance, such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirements.</p> <p>This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjoined with any other antenna or transmitter.</p>	<p>-Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p> <p>Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance, such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirements.</p> <p>This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjoined with any other antenna or transmitter.</p>	<p>10. FAQ</p> <p>Q1: Does this product use real-time global GPS tracking? A1: No. It does not have a built-in GPS module. The device uses Bluetooth to connect and relies on nearby Apple devices to update its approximate location on the map.</p> <p>Q2: If the location hasn't updated for an extended period, it may be due to a lack of Apple devices within range (about 1 km) or weak cellular signal.</p> <p>Q3: Which device models are compatible with this device? A2: This device is compatible only with iPhone and iPad models running iOS or iPadOS 14.3 or later.</p> <p>Q4: Unable to pair the device again? A3: The device may have been previously paired and is still linked to the original Apple ID. Please use the device to remove the previous pairing before trying again.</p> <p>Q5: Can the battery be replaced? A4: The device has a built-in, non-replaceable battery. We do not recommend disassembling it, as this may damage the outer casing and affect its performance.</p> <p>Q6: Can Android users use this Item Finder? A5: Currently, it only supports Apple devices. iPhones must be running iOS 14.3 or later, as required by Apple. Otherwise, the device cannot be connected.</p> <p>Model: H-001 FCC ID: 2ABEH-H001</p> 