




**AP11 Kit
AP129
AP109
K88
K129
USER MANUAL**

Thank you for purchasing and using this product. In order to bring you a better experience, please read the manual carefully and keep it for future reference.

ENGLISH

Product Introduction



Product Features


- Magnetic installation
- Slim design, easy to carry
- Multi-touch for easy operation
- Wireless connection
- Sleep function, saving energy
- Button backlighting, better experience of using low-light environments

Maintenance



Store at room temperature. Charging with normal voltage. If you don't use it for a long time, you need to charge the keyboard every 2 months.

Power on and Power off



- Dial to "Green" to power on
- Dial to "Red" to power off

Product Parameter

Model: AP11 Kit

Product function: Keyboard input/multi-touch

Main material: PU+ABS+Aluminum alloy

Operating distance: ≤10m

Connection mode: Bluetooth

Interface type: Type-C

Working current: <10mA

Battery capacity: 480 mAh

Charging current: 240mA

Standby time: ≥30 days


Charging time: < 2h

Size: 248mm*194mm*18mm

Applicable models: 11 inch iPad Pro (1 / 2 / 3 / 4), iPad Air (4 / 5)

Wireless Connection

- ① Slide the power switch to green. The red power indicator turns off after 1 second and the blue pairing indicator flashes.



- ② Open the settings interface of your iPad, turn on Bluetooth, leave Bluetooth on "ON" or green.



- ③ Click "AP11 Kit" in "OTHER DEVICES". Enter the window and click "Pair". Pairing succeeded, the blue light is constantly on.



* Notice:

1. The keyboard will automatically connect your iPad after successfully connecting the first time.

2. If you want to connect another device, please find "AP11 Kit" in the Bluetooth connected device of your iPad, click "Forget This Device".

Indicator Lights and other Description

1. Low power state: The red light flashes
2. Charging: The red light is constantly on
3. Fully charged: The green light is constantly on
4. Request pairing: The blue light flashes
5. Majuscule: The white light is constantly on; Minuscule: The white light is off
6. Resting: Keyboard standby for 10 minutes into sleep mode
7. Go back to sleep: Press any key to connect back
8. Most of the obstacles to use for unknown reasons can be solved by restarting the keyboard or iPad

IOS Touch Gesture

| | | | |
|--|--|---|--|
|  | Tap: Press with one finger until it feels a little bit pressed. |  | Tap and hold: Press and hold with one finger. |
|  | Drag: Tap and hold the item, then slide your finger on the touchpad to move it. |  | Wake up iPad: Tap the trackpad or if you are using an external keyboard, press any key. |
|  | Open the Dock: Swipe the pointer across the bottom of the screen with a single finger. |  | Go to the home screen: Swipe the pointer across the bottom of the screen with one finger. After the Dock appears, swipe the pointer across the bottom of the screen again. |
|  | Pull the display sideways: Swipe the pointer across the right edge of the screen with a single finger. To hide the side pull, swipe right again. |  | Open the "Control Center": Move the pointer with one finger to select the status icon at the top right, and then tap, or select the status icon at the top right, and then swipe up with one finger. |
|  | Open "Notification Center": Use one finger to move the pointer to select the status icon at the top left, and then tap, or use one finger to move the pointer near the top center of the screen. |  | Scroll up or down: Swipe up or down with two fingers. |
|  | Scroll left or right: Swipe left or right with two fingers. |  | Zoom in: place two fingers close together, spread to zoom in, or pinch to zoom out. |
|  | Go to the home screen: Swipe up with three fingers. |  | Open the APP switcher: Swipe up with three fingers, pause for a moment, and then lift your finger. Or pinch your fingers together, pause for a while and then lift your fingers. |
|  | Switch between open apps: Swipe left or right with three fingers. |  | Turn on the Today view: When the home screen or lock screen is visible, swipe right with two fingers. |
|  | Open search from the home screen: Swipe down with two fingers. |  | Auxiliary tap: Two-finger tap the icons on the home screen, the mail in the mailbox, and the "Camera" button in the "Control Center" to display its quick operation menu. You can hold down the Control key and tap the trackpad |

Keyboard Identification



Instructions:

1. Backlight brightness switching function: Press the backlight button  to switch brightness, three gears of switch in total.

2. Shortcut Icon on the Digital Silk Screen can be achieved by pressing the fn key combination.

For instance,  in  , press  and  combination keys at the same time.

Shortcut Key

⌘ Fast switching language and typewriting

control + space Switching input method

control + tab Switch labels

control + cmd + space Call up emoticons and symbols

cmd + Z Undo

cmd + X Cut

cmd + C Copy

cmd + V Paste

cmd + A Select all

cmd + S Save

cmd + F Find

cmd + shift + 3 Capture all screens to file

cmd + shift + 4 Capture the selected screen area to a file

⌘ + H Go to the Home screen

cmd + spacebar Search

cmd + tab App switch apps

⌘ + A Displays the Dock

shift + ⌘ + A Displays the app repository

⌘ + Q Quickly open notes

⌘ + S Siri

⌘ + C Control center

⌘ + N Notification Hubs

⌘ + M Displays keyboard shortcuts

⌘ + ↑ App switcher

⌘ + ← Switch to the previous app

Shortcut symbol

option + R: ®

option + G: ©

option + =: ≠

option + >: ≥

option + <: ≤

option + P: π

option + V: √

option + J: Δ

option + Z: Ω

option + X: ≈

option + M: μ

option + S: β

option + W: Σ

option + 5: ∞

In the application:

cmd + H Hide the current application window

cmd + tab Go to the next recently used application

Text processing:

cmd + B Toggles the bold display of the selected text

cmd + → Moves the cursor to the end of the current line

cmd + ← Moves the cursor to the beginning of the current line

cmd + ↓ Moves the cursor to the end of the document

cmd + ↑ Moves the cursor to the beginning of the document

option + → Moves the cursor to the end of the next word

option + ← Moves the cursor to the beginning of the previous word

control + A Moves to the beginning of a line or paragraph

In the browser:

control + tab Go to the next tab

cmd + L Jumps to the address bar

control + shift + tab Go to the previous tab

cmd + = Enlarge page

cmd + - Shrink page

IC Caution: This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.