

<div data-bbox="165 221 320 263">RUSAM</div> <div data-bbox="206 333 445 645"></div> <div data-bbox="160 676 480 729">RUSAM Wireless EarbudRU53 Product Manual</div>	<div data-bbox="532 217 794 242">Specification of Product</div> <div data-bbox="532 250 780 494"><p>Model of Product: RU53 Version: V5.4 Effective Distance: Approx. 10m Speaker Diameter: φ14.2mm Impedance: 22Ω Frequency Respinse: 20Hz-20KHz Microphone Sensitivity: -42dB±3dB Earphone Input: 5V≈40mA Charging Case Input: 5V≈380mA Charging Case Output: 5V≈100mA Earphone Battery Capacity: 40mAh Charging Case Battery Capacity: 380mAh Duration: Approx. 5.5 H (Earphone) Earphone Charging Time: Approx. 1.5 H Charging Time of the Charging Case: Approx. 2 H</p></div> <div data-bbox="532 539 614 564">Item list</div> <div data-bbox="532 589 867 732"><div>Charging case *1</div><div>Headphones *1</div><div>Charging cable *1</div><div>Instruction *1</div></div>	<div data-bbox="975 214 1191 264">Welcome to RUSAM Wireless Earbud</div> <div data-bbox="978 320 1170 585"></div> <div data-bbox="1007 642 1158 663">Take out and pair it</div> <div data-bbox="914 667 1249 715"><p>When using for the first time, take out the left and right earphones at the same time. When the blue light of the earphones flash , the earphones will enter the automatic pairing mode.</p></div>	<div data-bbox="1284 225 1627 249">How to wear headphones correctly</div> <div data-bbox="1310 263 1592 725"></div>	<div data-bbox="1697 263 1974 725"></div>	<div data-bbox="2117 225 2315 249">Product Description</div> <div data-bbox="2076 295 2358 739"></div>	<div data-bbox="2513 225 2676 249">Touch Operation</div> <div data-bbox="2431 315 2760 659"><div data-bbox="2431 315 2760 340">Connect with Bluetooth device</div><div data-bbox="2448 396 2553 509"></div><div data-bbox="2600 389 2734 659"></div><div data-bbox="2440 532 2594 642"><p>Open the Bluetooth settings option of the Bluetooth device to be paired, enter the options and find the Bluetooth pairing name of the headset " RU53 ". Click the pairing name to pair.</p></div></div>
<div data-bbox="174 785 465 810">Indicator Light Description</div> <div data-bbox="154 862 256 975"></div> <div data-bbox="273 842 457 954"><ul style="list-style-type: none">• When the headset is turned on: the blue light flashing• When the headset is turned off: After the blue light is on, it goes out• Pairing status: Blue light flashing• Connection successful: no light</div> <div data-bbox="174 1031 241 1117"></div> <div data-bbox="273 992 492 1205"><ul style="list-style-type: none">• Headphone Charging: The blue light on the digital display screen of the charging case is always on, and the blue light on the earphones is always on. After being fully charged, the blue light on the earphones goes out, and at the same time, the digital display screen in the charging case goes out.• Charging of the Charging case: The digital display screen of the charging case flashes, and after being fully charged, the digital display screen of the charging case always lights up at 100.</div>	<div data-bbox="550 781 832 1027"></div> <div data-bbox="532 1045 879 1205"><p>Power On Auto power on: The Earphone are taken out of the charging case, the Earphone will be powered on, with the prompt sound of "Du". Manual power-on: Long press for 3 seconds, the Earphone will be powered on, with the prompt sound of "Du".</p><p>Power Off Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du". Manual power off: Long press for 5 seconds, the Earphone will be powered off, with the prompt sound of "Du".</p></div> <div data-bbox="532 1216 867 1299"><p>Note: After powering on, if it is not paired with a Bluetooth device for 3 minutes, it will automatically shut down; If it is not connected to a Bluetooth device after 3 minutes, it will automatically power off after 3 minutes, with the prompt sound of "Du". "</p></div>	<div data-bbox="1019 785 1138 810">Once Press</div> <div data-bbox="978 816 1191 1020"></div> <div data-bbox="1013 1069 1156 1094">Double Press</div> <div data-bbox="943 1100 1223 1304"></div>	<div data-bbox="1397 785 1517 810">Long Press</div> <div data-bbox="1348 848 1566 1027"></div> <div data-bbox="1380 1045 1531 1062"><p>Wake up voice assistant</p></div> <div data-bbox="1281 1103 1633 1166"><p>When using both ears, press and hold the left ear multi-function button for 2 seconds to activate the voice assistant. When using one earphone, press and hold the left (or right) earphone for 2 seconds to activate the voice assistant</p></div> <div data-bbox="1418 1177 1496 1194"><p>Phone mode</p></div> <div data-bbox="1324 1205 1589 1257"><p>Press and hold the left (or right) ear multi-function button for two seconds: call rejection</p></div>	<div data-bbox="1770 785 1901 810">Triple Press</div> <div data-bbox="1697 816 1988 1020"></div> <div data-bbox="1688 1020 1997 1071">Switch between game mode and music mode</div> <div data-bbox="1671 1089 2006 1241"></div> <div data-bbox="1677 1251 1997 1299"><p>Note 1: When using one earphone, you cannot switch between game mode and music mode. Note 2: The factory setting defaults to music mode</p></div>	<div data-bbox="2134 785 2297 837">Clear Bluetooth pairing history</div> <div data-bbox="2064 848 2364 896"><p>When both ears cannot be paired, you need to clear all connected devices and click the left and right earphones 5 times at the same time.</p></div> <div data-bbox="2047 914 2382 1117"></div> <div data-bbox="2146 1149 2285 1166"><p>Wireless pairing mode</p></div> <div data-bbox="2050 1170 2382 1265"><p>1. When there is no pairing record for the left and right earphones, the left and right earphones will automatically pair after they are turned on. After successful pairing, there will be two beeps. 2. When the left and right earphones have pairing records, they will automatically connect back when they are turned on, and the prompt will sound "beep"</p></div>	<div data-bbox="2518 1031 2670 1066">RUSAM</div>

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired
2. Changes or modifications not expressly approved by the party responsible for compliance could void the
to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,
FCC Rules. These limits are designed to provide reasonable protection
interference in a residential installation. This equipment generates uses and can
may cause harmful interference to radio communications. However, there is no guarantee that
installation. If this equipment does cause harmful
, which can be determined by turning the equipment off
encouraged to try to correct the interference by one or more of the following
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to whichthe receiver is connected.