

Quick User Guide

WiFi Camera

Download CAM720 APP from APP store or Google play, or by Scanning the QR code above.

Sign up an account by email and login, please read the instructions carefully before use.

Camera introduction

Note: The reset button position will be different for different models, and the picture is for reference only

Mic

White LEDs

Reset button

SD card slot

Call buttons

Power supply

Lens

Lens

Reset button

SD card slot

Power port

1

Antenna

MIC

Network port

Power port

White LEDs

Infrared LEDs

Speaker

Reset button

SD card slot

Card cover

2

E27 base

Lens

Microphone

SD card slot

Lens

Reset Key

Speaker

White LEDs

Reset button

SD card slot

3

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions.
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
The distance between user and products should be no less than 20cm.

4

Information to User

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

5

Q1:What should I pay attention to before WIFI connection?

A1:APP permission: PLS turn on GPS and all permissions,select"allow"; OS phone:pls enable location action by setting:privacy>location ser>vices>cam720 APP>enable(please location,select"always" always"

Q2:What should I pay attention to before Wiredconnection?

A2:Ethernet cable:pls check the cable is working and check the indica for of the network port is always on

NOTE: pls confirm the cellphone connected the same wifi of the router that camera connected.

Q3:How to do if the camera is often offline?

A3:Adapter: pls check the adapter and outlet for the camera, or check the camera's record, if there are some broken records, the problem is in power;camera can record without wifi

Network: pls check the network is it normal

APP permission: pls check mobile network permission on the APP is enable, otherwise, the APP can't work under mobile network.

Reconfigure the camera: delete the camera from the APP> add the camera after reset the camera as the first connection

6

Sign up & Login

1.Register an account: Click"sign up"> enter Email, set your APP pass word, check the verified code

2.Login

Note: if you don't want register an account, it can't remote, but you can use stand alone mode to view the camera, This mode only support Local view

7

WiFi connection

Power and Reset the camera: PLS plug the adapter for the camera, Reset the camera by long press the reset button for 5 seconds until you hearing "Di~" camera will do self-inspection after "Di~"2 times.

Requirement Before WiFi connection: pls read Q1 above: Don't ban permissions of the APP

NOTE: some models only support 2.4GHz WiFi, cellphone connected 2.4G WiFi for first connection; if camera support 2.4G/5G dual-band WiFi, pls choose the right WiFi according to the place you want to install (2.4GHz signal transfer distance is longer, 5GHz is shorter but faster in speed).

Keep the camera and router at a distance of two meters

The device connects to the router via WiFi

8

1.In the APP: click"+> select"WIFI connection"

2.Check"configure the network when you hear the device tone"> Tap"next step"

9

3.Follow the Tips Shown in the APP(pls connect WiFi to JAA-*** or JAA-***, and then back to Cam720 APP)to find the Camera's WiFi(namedJAA-***, JAA-***),after connected it pls back to cam720 APP

10

4. Enter the right password of the WiFi that your phone connected to, Tap"Next Step"

5. When the device is connected, pls wait patiently until camera is online",then click the video to view

11

Bluetooth configuration

1. Please confirm that the Bluetooth function is turned on.

2. After resetting the camera, wait for it "Di" two sounds, until camera completes self-test.

3. In the APP: Click "+" and wait for 1~2 seconds for the APP to automatically search for the camera Bluetooth signal.

12

4. Select the Bluetooth signal of the camera, input the WiFi password and click Next.

5. Wait patiently during Bluetooth network configuration, please do not exit halfway.

Note: Please ignore if you don't need for Bluetooth network configuration. If you need to use it again, please close APP then re-open.

Bluetooth connection

Connecting device

1.

Device ready

Device ready

Device ready

13

Wired Connection

Plug the power supply and Ethernet cable to the router: PLS plug the adapter for the camera, and connect the camera with the Ethernet cable to the router.

Reset the camera: Long-press the reset button about 5~8s until you hearing Prompted, added wired connection to connect it.

NOTE: pls read Q2 above if there is a problem in wired connection if the camera has a Network port, it supports wiredWiFi connection, otherwise, pls select wifi connection to connect.

Connect to the router LAN port through a network cable

14

1. In the APP,click"+> select"network cable connection"

2. Search and select the IP of the camera,click to add

3. Click the video to view until hearing "camera is online"

15

1 Return to the device list

2 Share the device

3 More function settings

4 Switch image effects

5 Switch into Full-screen image

6 Turn on screen record function

7 Screenshot to save the image

8 Turn on voice intercom

9 Turn on the microphone

10 More functions

11 PTZ rotation control

12 Detection of events

13 SD card Playback

14 Cloud Playback

15 Add more cameras

16 Modify the device name

17 Start Live video

18 Subscribe Cloud storage

19 More Functions setup

20 Detection of events

21 User information

16

1 Back to the device list

2 Modify the device name

3 Share equipment

4 SD card setup

5 Detection alarm settings

6 Buy cloud storage

7 Image Flip: upside down

8 Choose a call mode

9 Enable/Disable Auto tracking

10 Choose night vision mode

11 Set the time zone

12 Switch WiFi network

13 Camera information

14 Camera version number

15 Delete the camera

16 Transfer the camera to another account

17

Share

Share your camera with your friends and families

1. Your friend should have an account of cam720 APP.

2. In main account, enter the Email of the friend APP account or scan the QR code of the account to share it.

3. Freely set the permission on this shared account.

18

19

Playback

1. Turn on the playback function and two Record method available: SDcard record(8~256G) and Cloud Record.

2. New users can get a trial cloud storage for free, pls don't miss it.

3. SD card record supports 3 record modes: 24/7 continuous, motion-triggered, scheduled record.

20

21

Installation

Indoor Camera--stand assembly

1. This camera can be placed on the desktop, or do cell or Wall mounted.

2. Attach the bracket to the wall and make a mark on the hole to punch holes, and use a 6mm drill bit to get the holes, then Stuff the rubber stopper into the hole.

3. Align the bracket with the hole position and tighten the screws. Fix the body, hold the body and turn it tightly.

22

23

Outdoor camera

1. Put the other end of bracket A together with the slot of bracket B, and then just push it down.

2. Select a suitable location and install expansion screws on the wall, for example, if it's a wooden wall, expansion screws are not requirement.

3. Align the bracket with the hole position and tighten the screws.

24

25

Important Use Notice

1. The use of unapproved or incompatible power adapters may cause fire, explosion or other dangers.

2. This product and accessories contain some small parts to avoid children contact and cause swallowing small parts, causing suffocation or other hazards, in addition, this product is not a toy, children should be used under adult supervision.

3. Please use this product within the appropriate temperature range. When the ambient temperature is too high or too low, it may cause errors, avoid rain or moisture on the product and its accessories, so as not to affect the use of the product.

4. Suitable for equipment, suitable for areas with an altitude of 2000 meters and below.

5. WiFi device should be under a good wifi signal area, pls avoid choosing a closed environment installation which may cause bad signal.

26

Important Use Notice

1. Failed in connection at first connection?
PLS view the operation video at last page(Scan the QR code to view), and pls view wifi connection steps from Page6, if still failed, pls message seller to get support, we also offer online support if you need.

2. Change a router, camera is offline?
pls delete the camera from the APP, and take the camera to near the new router power and reset it, search and add it.

3. Stop record?
1. Check the status of the SD card in the APP
2. Check the record setup support
3. Format SD card
4. change a SD card to test
5. Message Seller to get

4. Camera is offline?
Read the Q3 at page4 and follow it to check, if there is further question, pls message seller to get support

5. The instructions are not detailed enough?
It's general quick user guide, so less many details, pls contact seller to get the E-user manual and operation video according to your order.

27

After-sale Service & Tech Support

We offer a one-year warranty and lifetime technical support. Asking as there is any problem, please feel free to contact the purchase store, we will quickly provide an effective solution.

E-mail: technicalreply@qacstv.com market@qacstv.com

By scanning the QR code below to access YouTube, Select the right operation video for your camera according to APP and Model of the camera Or message seller to get the operation video directly.

28

29