

Accessories

RGB WirelessCharging R100 x1

Data cable x1

Manual x1

Producticon

Button

Wireless Charge

Light

Change port

Cooling Fan

Product Description

Short press:

①Warm Light Mode

②Color Auto Mode

③Color Rhythm Mode

④Charging Mode:

Not charging: red light is always onChareing: blue light cycleFully charged; the color is always on

Long press: Brightness Adjustment

Product Parameters

Product Name: RGB Wireless Charging R100

Product Model: R100

Material: ABS

Product Size: 122x122X31mm

Input:USB DC5V/2A.DC9V/2A

Net Weight:~120g

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body:
Use only the supplied antenna.