




The image shows a white Dipster Waterproof Wireless Speaker. It has a rectangular shape with rounded corners and a thin, light-colored frame. The front face is mostly white with a small circular dipole speaker grille in the center. The top edge features a row of small circular ports. The side shown has a power button and a small circular port. The speaker is shown from a three-quarter perspective, slightly angled, with its back panel visible on the right side, showing a textured pattern and a small circular port.

no box



3



5

2. AV
3. Do
4. Do
- clean
5. Use
- volta
6. Do
- temp

ns

extremely hot and
the battery and circu
the product.
ct.
ical products or c

Connecting the po
us damage.
ace the product n
of explosion.

6

7

FCC statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.