

## INSIDE

**NOTES**

**READING THE POWER METER**  
Checking your remaining power -  
White lights indicate how much juice is left in your battery pack. If there are four white lights showing, you're fully charged. Three indicates a 75% charge, two for 50% and one for 25%.

**Checking your charging function -**  
A red light indicates that the powerbank is turned on, but is not actively charging a device. A green light indicates a secure connection and power delivery.

**SAFETY**

- If you're not using your power bank often, please charge fully at least every three months.
- A small amount of heat production is normal. Please be aware of optimal placement of the power bank, as incorrect placement on your phone can produce more heat.
- Keep device dry and do not clean with chemical agents
- If you are disposing of this power bank, please recycle at your nearest battery recycling station.
- Usage by children should be supervised by adults.
- Do not crush, disassemble or otherwise destroy this device.
- Do not store in hot, humid conditions.
- Make sure your device is compatible with your power bank before using.

**FAQ**  
My device isn't charging. What is the problem?  
• Make sure power is on, and the power bank is charged.  
• Make sure you've placed it in the proper position.  
• Make sure your device is compatible with the power bank.  
• If it still doesn't work, please visit [cellhelmet.com](http://cellhelmet.com) for support.

FCC Statement:  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
—Reorient or relocate the receiving antenna.  
—Increase the separation between the equipment and receiver.  
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used in portable exposure without restriction.

**PW02**  
**FAST CHARGE POWER BANK**

**DETAILS**

On/Off Button

Super-Strong Magnetic Connection (15W Output)

Type C Input & Output

Power Meter