



Wireless karaoke set User manual

Product Name: Wireless karaoke set
Product model: P6
Rated power: 10W
Rated input: 5V-1A
Product size:
20.3*6.9*9.6cm/7.99*2.72*3.78inch(speaker)
17.2*4.3*4.3cm/6.77*1.69*1.69 inch(microphone)
Product material:
ABS+PVC+PU+leather+electronic components
Battery capacity:
2400mAh (speaker)/800mAh (microphone)
Wireless transmission distance: 10M barrier free
Charging time: 4H
Usage time: 4-5H

Speaker function indicator diagram




- ① Long press: switch on/off
Short press: Switch lighting mode
- ② Short press: pause/play
- ③ Long press: cancel the original sound
Short press: Switch AUX mode, wireless Mode, TF card mode
- ④ Long press: Previous track
Short press: Volume-
- ⑤ Long press: Next song
Short press: Volume+




*When using the product for the first time, please fully charge it first.

Microphone function indicator diagram



- ① On/off indicator light
- ② Long press: Turn on/off the microphone
Short press: Magic sound mode switching
- ③ Long press: Previous track
Short press: microphone volume+
- ④ Long press: Next song
Short press: microphone volume-



Wireless usage

Wireless connection to mobile phone
1. Audio power on: Press and hold the power on button for 3 seconds to turn on the device, and the wireless indicator light will flash;
2. Wireless connection: Turn on your phone's wireless connection and scan it. After searching for "P6", pair and connect. After connecting, you can hear a "ding dong" connection prompt sound in the audio system;
3. Open the mobile app and play music.
Note: After connecting to the phone once, the wireless device has a memory function and can automatically reconnect after turning on; If you need to disconnect, you can do so through the wireless settings on your phone.

Mic usage

1. Mic power on: Press and hold the power button for 3 seconds to turn on the microphone;
2. The wireless indicator light flashes, and the audio system is automatically paired.
If the wireless indicator light remains on, the pairing is successful;
3. Start karaoke, and the effect is better when the distance between the microphone and the speaker is within 10 meters;
4. If you only listen to music, you can short press the power button to turn off the microphone or long press the power button for 3 seconds to avoid whistling;
5. When the microphone has poor sound or does not turn on, it is necessary to charge the phone to replenish the battery.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.