



尺寸: 71.25 x120mm

<p><b>ULTREAN</b> <b>AI Nutriscale Hue</b></p>  <p>Ultrean Support: <a href="mailto:Support@ultrean.com">Support@ultrean.com</a> Model No.: JKS16</p>	<p><b>IMPORTANT SAFEGUARDS</b></p> <p><b>WARNING</b></p> <p>Please read and comply with all of the instructions and warnings provided in this manual before using the product.</p> <p><b>Important safety information</b></p> <ul style="list-style-type: none"> <li>Place the scale on a flat, dry surface before use.</li> <li><b>DO NOT</b> immerse the scale in water or corrosive liquids. If a liquid is spilled on the scale platform, immediately wipe the scale and clean with a soft cloth to avoid potential damage to the scale.</li> <li><b>DO NOT</b> exceed 33 lb weight capacity. An overload indicator will appear on the LED if the limit is exceeded.</li> <li>When replacing batteries, ensure that they are inserted with the correct polarity as indicated inside the battery compartment.</li> <li><b>DO NOT</b> mix new and used batteries to power the device.</li> <li>This scale is not intended for commercial or heavy-duty use.</li> <li>When the scale is not in use, it should be stored in a cool and dry environment.</li> <li>To clean the scale, simply use a soft cloth dampened with water to wipe the surface of the platform.</li> <li>If the scale fails to turn on, please ensure to check if the device is out of power and replace with a brand-new battery if necessary.</li> </ul>	<ul style="list-style-type: none"> <li>If the scale is not in use for an extended period, take out the batteries to extend the scale service lifetime.</li> <li>Replace the batteries low-battery indicator "Lo" is displayed to ensure the highest accuracy.</li> </ul> <p><b>GETTING TO KNOW YOUR CROWNFUL AI NUTRISCALE HUE</b></p> <p><b>1. PRODUCT DIAGRAM</b></p>  <p>1. LED Display      4. Battery Compartment 2. Power/Auto-Tare Button      5. Anti-Skid Padding 3. Unit Selection</p> <p><b>2. PACKAGE INCLUSION</b></p> <p>1 x CROWNFUL AI Nutriscale Hue      1 x User manual 3 x 1.5V AAA Batteries (Pre-installed)</p> <p><b>NOTE:</b> The provided 3 x 1.5V AAA Batteries are non-rechargeable batteries and should not be recharged.</p>	<p><b>3. SPECIFICATIONS</b></p> <table border="1"> <tr> <td>Model No.:</td> <td>JKS16</td> </tr> <tr> <td>Weight Capacity:</td> <td>15000g / 529oz / 33lb / 15000ml / 15000ml (milk)</td> </tr> <tr> <td>Units:</td> <td>g / oz / lb / ml / ml (milk)</td> </tr> <tr> <td>Measurement Increments:</td> <td>2g / 0.1oz / 1ml</td> </tr> <tr> <td>Auto-Off:</td> <td>120 seconds of inactivity</td> </tr> <tr> <td>Battery powered:</td> <td>3x 1.5V AAA batteries (Pre-installed)</td> </tr> <tr> <td>Product Dimensions:</td> <td>5.5" x 7.0" x 0.6" inch / 14" x 17.9" x 1.6" CM</td> </tr> <tr> <td>Product Weight:</td> <td>0.52lb / 235g</td> </tr> </table> <p><b>OPERATING INSTRUCTIONS</b></p> <p><b>GENERAL OPERATION</b></p> <p>Place the scale on a flat, dry surface before use. Press the "O" button to turn on the scale. Wait until the screen displays "000" before measuring.</p> <p>Place the object to be measured in the center of the weighing platform. Allow the scale a few seconds to adjust to the weight of the object. Once stabilized, the final measurement will be shown on the LED screen.</p> <p><b>TARE FUNCTION</b></p> <p>The tare function allows you to measure objects in a container without having to include the container's weight in the final measurement. Turn on the scale and wait for the screen to display "T". If the screen</p>	Model No.:	JKS16	Weight Capacity:	15000g / 529oz / 33lb / 15000ml / 15000ml (milk)	Units:	g / oz / lb / ml / ml (milk)	Measurement Increments:	2g / 0.1oz / 1ml	Auto-Off:	120 seconds of inactivity	Battery powered:	3x 1.5V AAA batteries (Pre-installed)	Product Dimensions:	5.5" x 7.0" x 0.6" inch / 14" x 17.9" x 1.6" CM	Product Weight:	0.52lb / 235g
Model No.:	JKS16																		
Weight Capacity:	15000g / 529oz / 33lb / 15000ml / 15000ml (milk)																		
Units:	g / oz / lb / ml / ml (milk)																		
Measurement Increments:	2g / 0.1oz / 1ml																		
Auto-Off:	120 seconds of inactivity																		
Battery powered:	3x 1.5V AAA batteries (Pre-installed)																		
Product Dimensions:	5.5" x 7.0" x 0.6" inch / 14" x 17.9" x 1.6" CM																		
Product Weight:	0.52lb / 235g																		

<p>does not display "000" automatically, press the "O" button to auto-adjust to zero. Place the desired object which is to be excluded, on the center of the measuring platform.</p> <p>Press the "O" button to tare the current weight of the object. The screen should now display zero.</p> <p>Place the desired item(s) to be weighed on the center of the measuring platform or within the tared container to calculate the net weight of the desired item(s).</p> <p><b>BATTERY REPLACEMENT</b></p> <ol style="list-style-type: none"> <li>Open the battery compartment cover located on the backside of the scale.</li> <li>Take out the used batteries and dispose of them properly.</li> <li>Install new AAA batteries, taking note of the correct polarity displayed in the battery compartment.</li> <li>Reseal the battery compartment.</li> </ol> <p><b>Note:</b> When you use it for the first time, you need to tear off the insulation film of the battery.</p> <p><b>AUTOMATIC POWER OFF</b></p> <p>To conserve battery power, the scale will automatically turn off after 180 seconds of inactivity.</p> <p><b>MANUAL POWER OFF</b></p> <p>Press and hold the "Power" button for 3 seconds to manually turn off the digital scale at any time.</p>	<p><b>TROUBLESHOOTING</b></p> <table border="1"> <thead> <tr> <th>ERROR MESSAGE</th> <th>REASON</th> <th>SOLUTION</th> </tr> </thead> <tbody> <tr> <td>"-Ld"</td> <td>Scale overload. Maximum weight capacity: 33lb(15kg)</td> <td>Remove the object from the scale to avoid damage.</td> </tr> <tr> <td>"LO"</td> <td>Battery power is low. Shutting down soon.</td> <td>Install new batteries.</td> </tr> <tr> <td>The LED light is very dim.</td> <td>Battery power is low.</td> <td>Install new batteries.</td> </tr> </tbody> </table> <p>If your problem is not listed, please contact Customer Support at <a href="mailto:support@ultrean.com">support@ultrean.com</a>.</p> <p><b>FCC STATEMENT</b></p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>Reorient or relocate the receiving antenna.</li> <li>Increase the separation between the equipment and receiver.</li> <li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> </ul>	ERROR MESSAGE	REASON	SOLUTION	"-Ld"	Scale overload. Maximum weight capacity: 33lb(15kg)	Remove the object from the scale to avoid damage.	"LO"	Battery power is low. Shutting down soon.	Install new batteries.	The LED light is very dim.	Battery power is low.	Install new batteries.	<ul style="list-style-type: none"> <li>Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</li> </ul> <p><b>WARRANTY INFORMATION</b></p> <p>We offer a 1-year warranty on the product, starting from the date of purchase. During the warranty period, we will address any defects resulting from faults in materials or workmanship. Please contact us at: <a href="mailto:support@ultrean.com">support@ultrean.com</a> to launch a warranty claim.</p> <p>This warranty does not cover: Damage caused by improper use, normal wear and tear, or defects that have a negligible impact on the functionality or value of the appliance. Repairs performed by unauthorized persons or the use of non-original parts, which will void the warranty.</p> <p><b>CUSTOMER SERVICE</b></p> <ol style="list-style-type: none"> <li>If you have questions or concerns, please don't hesitate to contact us directly at <a href="mailto:support@ultrean.com">support@ultrean.com</a> or visit our website at: <a href="http://www.ultrean.com">www.ultrean.com</a>.</li> <li>Our hassle-free warranty and customer service team are here to provide satisfactory solutions for any issues you may encounter.</li> </ol>	<p>  @ultrean  Website: <a href="http://www.ultrean.com">www.ultrean.com</a></p> <p>  Scan to Follow Us</p> <p>Ver.250414</p>
ERROR MESSAGE	REASON	SOLUTION													
"-Ld"	Scale overload. Maximum weight capacity: 33lb(15kg)	Remove the object from the scale to avoid damage.													
"LO"	Battery power is low. Shutting down soon.	Install new batteries.													
The LED light is very dim.	Battery power is low.	Install new batteries.													