



# User's Manual

Product name: BLUETOOTH DONGLE

Product model: DYBT-011M

## How to use it:

\* Easy Plug into USB slot of device. No need other operation

## Features:

- \* Easy Plug in to use. No need other operation
- \* Bluetooth version: 5.0
- \* ISM Band: 2.4GHz(2.402-2.480GHz)
- \* Operation range: Class II. Up to 20M(No obstacles)
- \* Compatible with Linux/Windows XP/Vista/Windows7/8.1/10
- \* Full-speed USB 2.0 interface

## Technical Parameters

Commodity name:	BLUETOOTH DONGLE
Product model:	DYBT-011M
Product chip:	Realtek 8761BUV, Taiwan
Bluetooth version:	Bluetooth V5.0
Frequency range:	2.4GHz(2.402-2480MHz)
Use distance:	10M—20M
Rated voltage:	DC5V
Interface type:	USB
Transmission rate:	3.0Mbps (Nova 5 Pro Actual measurement 220KB/s)
Operating system:	Win7/Win 8.1/Win 10/Linux
Operating temperature:	-30 °C ~45 °C

## Caution:

- \* Please keep away from dusty and moisture environment
- \* This is not waterproof product, do not use it in the rain

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been tested and in compliance with SAR limits, users can obtain FCC/ISED information on RF exposure and compliance. This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.

L'appareil est testé pour répondre aux limites SAR et les utilisateurs peuvent obtenir des informations FCC/ISED sur l'exposition aux RF et la conformité. La distance entre le radiateur et le corps doit être d'au moins 5 mm lors de l'installation et du fonctionnement de l'appareil.

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

*Le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :*

- (1) l'appareil nedoit pas produire de brouillage, et*
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*