


技术要求	120克双胶纸W-50*H-78mm 单黑双面印风琴折页 页面尺寸:W-600mm*H-78mm	设计部门	设计部
		产品名称	X1
		绘图	
		日期	2024.8.1

**ORG BRO**



**X1 THERMAL LABEL PRINTER**

**USER'S GUIDE**

**General Description**



The indicator light indicates the working status.

Press and hold the power button to turn on/off the device.

Press the button to open the cover and insert the consumable.

**Charging Instructions**

- Input: 5V 1A. We recommend using a USB cell phone charger or similar device.
- For optimal performance, we recommend fully charging the battery when you first use the device.
- To maintain optimum battery health, we recommend charging your lithium battery every three months, even if it's not fully drained.
- Recommended charging time: 2 hours.

**Attention!**  
This product does not include a power adapter. To charge the device, you will need to purchase a compatible adapter. Choose an adapter with an output of 5V 1A for optimal performance and safety.

**Product Information**

Brand	ORG BRO
Name	Thermal Label Printer
Model	X1
Connection	Bluetooth
Resolution	203 DPI
Cutting Method	Tear by hand
Charging Port	Type-C
Product Size	107.5 x 76 x 30 mm
Battery Capacity	2000 mAh
Cassette Capacity	15 x φ 45 mm
Consumables	Gap / Continuous

**Status Indicator Light**

Green light	Working properly.
Red light	Out of paper, please load new one.
Red light flashing	Low battery.
Green light flashes slowly	Charging while turned off.
Light is off	Fully charged.

**ENJOY IT!**

If you have any questions, please contact our customer service team at [orgbro\\_service@outlook.com](mailto:orgbro_service@outlook.com).

**CE FC RoHS**

**FCC STATEMENT :**  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**WARNING:**  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

**RF WARNING STATEMENT:**  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Consumables**

- Open the cover.
- Install consumables.  
\* Be careful not to install it upside down.
- Close the cover.


**Connection**

**Support: iOS/Android**


- Power on the device by pressing and holding the power button until the indicator light is on.
- Download the XeasyLabel app by searching for "XeasyLabel" in Google Play or App Store, or scanning the QR code on the next page. App installation may require obtaining the necessary permissions.
- Open the app and tap the "+" icon in the top right corner. Then select your device from the list of devices that appear.

▲ If your device is not listed, double-press the power button on your device. Your device will print a QR code. Then use the scanner button at the bottom of the device's screen to scan the QR code to connect.

**QR Code for Download**



**Include in Package**



**Thermal Label Printer**

**Type-C charging Cable**

**User's Guide**