

TRANSMITTER SPECIFICATIONS

Model: WOV-TX300

Channel: 3CH

Frequency: 2.4GHz

Transmit Power: <100mw

A.LED

Solid red lights: Indicates the power is on and adequate battery power

Flashing red lights: Indicates the battery voltage is critically low.

Replace batteries

B.Power switch

C.Steering Trim

Adjusts the steering center point. Normally, the steering trim is adjusted until the vehicle tracks straight.

D.Steering Rate

Knob for travel adjustment on the steering

E.Throttle Trim

Adjusts the throttle neutral point. Normally the throttle trim is adjusted until the throttle signal width is under deadth area of starting up.

F.Channel 3

3 position momentary switch, middle position is neutral

For programming press up for A button, press down for B button

G.Steering Wheel

H.Throttle/Brake

I.Throttle Limit

Limits throttle output to 50/75/100%



Select 50% or 75% for less experienced drivers or when you are driving the vehicle in a small area.

J.Throttle (TH) Reversing

Move the switch to reverse the throttle channel

K.Steering (ST) Servo Reversing

Move the switch to reverse the steering channel




INSTALLING THE TRANSMITTER BATTERIES

This transmitter requires 4 AA batteries.

1. Open the battery cover from the transmitter.

2. Install the batteries as shown.

3. Close the battery cover.



CAUTION: Charging non-rechargeable batteries may cause the batteries to burst, resulting in injury to persons and damage to property.

CAUTION: Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to national regulations.

Age Recommendation: Not for Children under 14 years. This is not a toy.

NOTICE: This product is only intended for use with unmanned, hobby-grade, remote-controlled vehicles. Bsd racing disclaims all liability outside of the intended purpose and will not provide warranty service.

FCC Statement

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - —Reorient or relocate the receiving antenna.
 - —Increase the separation between the equipment and receiver.
 - —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - —Consult the dealer or an experienced radio/TV technician for help.
— Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

- This device complies with FCC SAR exposure limits set forth for an uncontrolled environment. The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. SAR compliance for using the equipment in close proximity to the human body has been evaluated at 0mm. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.