

SOUNDSTREAM

sabre

INSTRUCTION MANUAL

Content

Quick Start Guide	1
Technical Specifications	3
Connecting Sabre with TWS	5
Warning	6
Waranty Registration	7
FAQ	8
FCC Statement.....	9


Quick Start Guide

BLUETOOTH BUTTON

Short Press : Pairing On
Long Press : Unpair unit

TWS BUTTON

Short Press : TWS pairing
Long Press : Turn off Glow



“+” Short Press : Volume Increase
“+” Long Press : Next Track
Max volume warning tone

“-” Short Press : Volume Decrease
“-” Long Press : Previous Track

POWER BUTTON

Short Press : Play / Pause
Long Press : ON / OFF unit

Press & Hold TWS Button & “-” to change the color of the glow

What's in the Box?

- 1x Main Unit
- 1x Type-C to C Charging Cable


BLUETOOTH BUTTON

Blinking : Searching
Solid : Connected

TWS BUTTON

Blinking : Searching
Solid : Connected

Strap Hook
(Strap not included)



Strap Hook
(Strap not included)

POWER BUTTON

Solid White : Power ON

Blinking Red : Battery Low @ 20% with low battery warning tone

Blinking White :


- Slow Normal charging with 5V/3A
- Fast blinking Fast charging with 15V/2A

Technical Specifications


Transducer	: 64mm X 2 woofer , 20mm X 2 tweeter , 52 X 90mm X 2 Passive Radiator
Rated output Power (80W)	: 25W X 2 Woofer , 15W X 2 tweeter
Frequency Response	: 50Hz ~ 20kHz
Signal to Noise Ratio	: >80dB
Battery Type	: Li-ion polymer 44WH (eqv to 16.8V/2600mAh)
Battery Charge Time	: 2 hours (15V/2A) support QC
Music Playtime	: Up to 24hours (dependent on volume level and audio content)
USB Port	: Type C
Bluetooth Version	: v5.2
Bluetooth Profile	: A2DP 1.3 , AVRCP 1.6
Bluetooth transmitter range	: 2400MHz ~ 2438.5 MHz
Bluetooth transmitter power	: ≤ 10dBm (EIRP)
	: 2407 MHz ~2475MHz

Weight


W: 1010 g / 2.23 lbs



Dimension



Front




64mm
Woofer

20mm
Silk Tweeter


52 X 90mm
Passive Radiator

Back



USB TYPE C charging 15V/2A (QC) - Full charge in 90mins


Connecting Sabre with TWS



*The interference and blockage might shorten the transmission distance

WARNING

**This speaker is waterproof
with IP67 rating**



To protect battery lifespan, fully charge at least once every 3 months. Battery life will vary due to usage patterns and environmental conditions.



When using an external adapter, the output voltage/current of the external adapter should not exceed 15V/2A.




Chemicals, salt or "foreign particles" in the water or sea can damage the waterproof seal or corrodes the connector surface over time if not rinsed off after use. After a liquid spill or rinse, it is important not to charge your speaker until it is completely dry and clean. Charging when wet might damage your speaker and cause electric shock.




Do not expose Soundstream Sabre to liquids without removing cable connection. Do not expose Soundstream Sabre to water while charging. It may result in permanent damage to the speaker or power source.

Waranty Registration



Model : SABRE
COLOR : LUNAR DUST
SERIAL NO : A5P/1234567

FAQ



Scan to Download

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.