



Control Bar

Product Manual



● ABOUT CONTROL BAR



SPECIFICATION

Input (USB-C)

: 5V/2A

Output (USB-C)

: 5V/300MA

Size


: 351*24.8*45mm

Material

: ABS


2 GUIDE ON HOW TO POWER

1,Connect the Contrl Bar to the power 5V2A, The screen shows "LOADING" to Enter standby mode.





3 GUIDE ON HOW TO CHARGE


1.Press and hold Button 6 to enter the "FACTORY mode". The RGB light will turn on.



2.Rotating knob1 can adjust the brightness of RGB lights, while rotating knob2 can adjust the color of RGB lights



2.Press buttons 1-6, and the display screen will display numbers from 1 to 6.



4 ENVIRONMENT PROTECTION FIRST!

Do not throw away the device with the normal household waste at the end of its life, but take it to the authorized recycler for disposal. By doing this, you help to preserve the environment.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1.This device may not cause interference.

2.This device must accept any interference, including interference that may cause undesired operation of the device.

L' émetteur/r écepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes:

1.L' appareil ne doit pas produire de brouillage;

2.L' appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Cet é quipement respecte les limites d' exposition au rayonnement IC établies pour un environnement non contrôlé . Cet émetteur ne doit pas être localisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur. Cet é quipement doit être installé et utilisé à une distance minimale de 20cm entre le radiateur et votre corps.