

耳机操作说明




Music	■▶	- -	单击	- -	■▶	Music
Telephone	📞📞	- -		- -	📞📞	Telephone
	⏮		双击		⏭	
	🗨		三击		🗨	
	⏮		长按		⏭	

手表有电状态:耳机出仓自己开机配对,连接一次后开仓耳机自动连接手机;

手表没电状态:耳机需手动开机,手表没电情况下,耳机进仓需手动关闭手机蓝牙。

TWS operation instructions



Music	■▶	- -	Click once	- -	■▶	Music
Telephone	📞📞	- -		- -	📞📞	Telephone
	⏮		Click twice		⏭	
Open Language Assistant			Click three times			Open Language Assistant
	⏮		Long press		⏭	

The watch is in a charged state: When the earphones are out of the compartment, they are paired and turned on by themselves. After connecting once, the earphones automatically connect to the phone when the compartment is opened;

Watch out of battery state: The headphones need to be manually turned on. When the watch is out of battery, the Wireless of the phone needs to be manually turned off when the headphones are stored.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user ' s authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.