


CH1025 manual

1: Key function indication




▶ /M paly

volume down

volume up

LED



DC5V input (AUX contact)

USB port

TF card

on-off

function	
Bluetooth Mode	Radio Mode
Key M: Play/Pause	Key M: Automatically search channels
Key "-": Previous song	Key "-": Previous channel
Key "+": Next song	Key "+": Next channel
Long press on "-": Lower volume	Long press on "-": Lower volume
Long press on "+": Raise volume	Long press on "+": Raise volume
LED light button: on/off	LED light button: on/off
USB Plays Mode	TTF Plays Mode
Key M: Play/Pause	Key M: Play/Pause
Key "-": Previous song	Key "-": Previous song
Key "+": Next song	Key "+": Next song
Long press on "-": Lower volume	Long press on "-": Lower volume
Long press on "+": Raise volume	Long press on "+": Raise volume
LED light button: on/off	LED light button: on/off

2: Technical specification

basic specification	
Bluetooth name	1025
Product Type	Portable Bluetooth Speaker
storage type	TF card &U disk （support GPT format storage device ）
power supply	Built-in 18650 3.7V/1200mAh battery
	working time 1.5-8H
	charging time 4-5H
	standby 10minutes
Speaker	1.8 inches
output	5W3Ω
frequency range	100Hz-20KHz
Bluetooth version	Bluteeth5.1
USB	support USB2.0 compatible with USB2.1
player	MP3
play format	MP3:8Kbps-32Kbps
size	180×55×88mm
N.W.	325g±10g （built-in battery included ）

3: Announcements

- ◆ Please read this instruction.
- ◆ Please read the instructions for the copy.
- ◆ Please store and use this product at room temperature.
- ◆ Do not use this product near sources of heat, such as radiators, heat regulators, stoves, or other instruments that generate heat (including amplifiers).
- ◆ Do not block the opening of the speaker and do not insert objects into the speaker's ventilation holes or slots.
- ◆ Do not throw the product to avoid damage due to falling.
- ◆ Please use a charger with the rated voltage specified for the speaker to charge it.
- ◆ If the cable does not match your device, please contact the seller.
- ◆ Please adjust the speaker to an appropriate volume to avoid harm to your hearing.
- ◆ In case of any damage to the device, professional maintenance personnel should be consulted for repair promptly. Unauthorized disassembly will void the warranty.
- ◆ There is a risk of explosion if the battery is replaced improperly. Only batteries of the same type or equivalent type should be used for replacement.
- ◆ The battery (or battery pack or combination battery) should not be exposed to warning labels such as exposure to sunlight, heating, or similar overheating environments.

4: Bluetooth contact guide

1. Turn on the speaker

Press the power button to turn on the speaker. After the beep sound, the indicator light will blink and wait for Bluetooth pairing.

2. Contact to the mobile device

Turn on the Bluetooth option on your mobile device, find SPEAKER in the Bluetooth device list, and you will hear a tone when the connection is successful. At the same time, the blue LED indicator will be on. In the future, as long as you keep the Bluetooth option on your mobile device, it will automatically connect.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.