

宽130mm，高185mm



Mini PC

T8 PRO



User Guide

Please read this user guide carefully before use retain for future reference

Specification of T8 pro


Hardware	LCD Display	8 inch 800*1280 IPS
	Touch Screen	5 point capacitive G+G
	CPU	Intel Alder Lake N95 Quad Core 3.4 GHz
	RAM	SO-DIMM DDR4 8G/16G
	Storage	PCIe M.2 / 128G/256G/512G
		SATA / HDD
	WiFi	WiFi 5/6E Optional
	BlueTooth	BT V5.0/5.3 Optional
	Speaker	BOX Speaker Optional
	MIC	Optional
I/O Interface	G-sensor	support
	Jack	3.5 * 1.35mm
	Internet	RJ45 * 2 1000M
	USB-A	USB3.0 * 4 + USB2.0 * 2
	HDMI	HDMI * 1
	DP	DP * 1
	TYPE-C	TYPE-C * 1
	TF-Card	TF-Card * 1
OS	Operating System	Window 11
Power	Input	AC 100-240V
	Output	TYPE-C PD 65W/DC 19V3A
Housing	Unit Size	211*129*40mm
	Material	Plastic
	Color	Black/Gray
	Net weight	685g

Product Illustration



- ① Power button (on/off)
- ② TF card port
- ③ USB 2.0 port
- ④ USB 3.0 port
- ⑤ Type-C full function
- ⑥ Earphone Jack 3.5mm
- ⑦ DC port(19V/3A)
- ⑧ HDMI port
- ⑨ DP port
- ⑩ USB 3.0 port
- ⑪ Gigabit LAN port
- ⑫ Gigabit LAN port

Additional description of internal interfaces



HDD Hard Disk Expansion Interface

Network connection



Connection with multiple devices



Touch Screen Operation



Special Function

Double Gigabit LAN port Design



Perform the following steps before using.

- ① Check that the package is intact, Disassemble and inspect accessories.
- ② Check the completeness of packing accessories
- ③ Understanding product Interface
- ④ Connect the power and start using



Procedurefor use

- ① Connecting the adaptor to the DC port
- ② The power indicator will show red
- ③ Press the power button
- ④ The power indicator will show green
- ⑤ The mini pc is starting up

Mini PC Pre-installed Windows 11 pro OS, Just follow the system prompts



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.