

真无线蓝牙耳机使用说明书		保修卡																																																					
<p>用Type-C充电线连接耳机到5V电源适配器。 (温馨提示：耳机电池电量低于3.3V开始播报低电提醒(声音提示：低电请充电)，红灯闪烁 (10%电量开始提醒))</p> <p>开机 关机</p> <p>开机状态:长按3秒触摸区域 手动开机 关机状态:长按5秒触摸区域 手动关机</p> <p>连接设备</p> <p>手机打开蓝牙搜索设备名连接即可使用 (超过5分钟无连接耳机会自动关机)</p> <p>操作控制 (左右耳均可)</p> <p>播放/暂停/接听电话/挂断电话----单击触摸区域 切换下一曲----双击触摸区域 切换上一曲----三击触摸区域 拒接来电----长按2秒触摸区域</p> <p>提示音</p> <p>用中英文提示音,默认英文,未连接状态5连击切换提示音。</p> <p>灯光 注意</p> <p>耳机开机红蓝灯交替闪烁 连上手机关闭耳机灯光 低电时有低电提示红色灯光 关机播报提示音时,红灯快闪,充电电流30ma 首次连接手机不要最大音量。 手机调整音量后同步跟随手机系统。 来电提示音同步手机铃声</p>		<p>用户信息</p> <table border="1"> <tr><td>用户名</td><td></td><td>联系电话</td><td></td></tr> <tr><td>邮箱</td><td></td><td>邮编</td><td></td></tr> <tr><td colspan="4">通讯地址</td></tr> <tr> <td rowspan="5">销售信息</td><td>商家名称</td><td colspan="2"></td></tr> <tr><td>联系地址</td><td colspan="2"></td></tr> <tr><td>联系电话</td><td>邮编</td><td></td></tr> <tr><td>生产日期</td><td colspan="2">销售日期</td></tr> <tr><td colspan="3">销售商盖章</td></tr> <tr> <td colspan="4">(维修机构填写)</td> </tr> <tr> <td>维修次数</td><td>维修单位名称</td><td>维修原因</td><td>维修时间</td> </tr> <tr> <td>第一次</td><td></td><td></td><td></td> </tr> <tr> <td>第二次</td><td></td><td></td><td></td> </tr> <tr> <td>第三次</td><td></td><td></td><td></td> </tr> <tr> <td>第四次</td><td></td><td></td><td></td> </tr> </table>		用户名		联系电话		邮箱		邮编		通讯地址				销售信息	商家名称			联系地址			联系电话	邮编		生产日期	销售日期		销售商盖章			(维修机构填写)				维修次数	维修单位名称	维修原因	维修时间	第一次				第二次				第三次				第四次			
用户名		联系电话																																																					
邮箱		邮编																																																					
通讯地址																																																							
销售信息	商家名称																																																						
	联系地址																																																						
	联系电话	邮编																																																					
	生产日期	销售日期																																																					
	销售商盖章																																																						
(维修机构填写)																																																							
维修次数	维修单位名称	维修原因	维修时间																																																				
第一次																																																							
第二次																																																							
第三次																																																							
第四次																																																							

WIRELESS EARBUDS PRODUCT MANUAL		WARRANTY CARD																																																					
<p>Connect the earphones to the 5V power adapter with a Type-C charging cable. (Warning tip: When the headset battery is less than 3.3V, it will broadcast a reminder of low battery (sound tip: battery low). Red light flashing (10% battery starts to remind))</p> <p>Boot up Shut down</p> <p>Shutdown status: Press and hold for 3 seconds to manually turn off the touch area</p> <p>Earbuds pairing Automatic pairing at boot</p> <p>Connect digital equipment</p> <p>You can use the mobile phone to turn on the Bluetooth to search for the device name to connect. (The headset will automatically shut down if it is not connected for more than 5 minutes)</p> <p>Operation control (both left and right ears)</p> <p>Play/pause/answer/end call----click on the touch area Switch to the next song----double-click the touch area Switch to the previous song----three-click the touch area Voice assistant----long press the touch area for 2 seconds Reject the call----long press the touch area for 2 seconds</p> <p>Reminder sound</p> <p>Use both Chinese and English prompt tones, default to English, and switch between 5 combo clicks when connected</p> <p>Pilot lamp</p> <p>The red and blue lights flicker alternately when the headphones are turned on Connect your phone and turn off the headphone light When the battery is low, there is a red light indicating low battery When the shutdown broadcast prompt sounds, the red light flashes quickly,</p> <p>Notice</p> <p>Charging current 30ma Just don't use the maximum volume when connecting your phone for the first time Synchronize with the phone system after adjusting the volume Incoming call/reminder tone synchronization with phone ringtone</p>		<p>User info</p> <table border="1"> <tr><td>Name</td><td></td><td>Contact number</td><td></td></tr> <tr><td>Mail</td><td></td><td>Zip code</td><td></td></tr> <tr><td colspan="4">Address</td></tr> <tr> <td rowspan="5">Sales information</td><td>The shop's name</td><td colspan="2"></td></tr> <tr><td>Address</td><td colspan="2"></td></tr> <tr><td>Contact number</td><td>Zip code</td><td></td></tr> <tr><td>Production Date</td><td colspan="2">Sales date</td></tr> <tr><td colspan="3">Seller stamp</td></tr> <tr> <td colspan="4">(Repair agency)</td> </tr> <tr> <td>Number of repairs</td><td>Maintenance unit name</td><td>Maintenance reason</td><td>Repair time</td> </tr> <tr> <td>first</td><td></td><td></td><td></td> </tr> <tr> <td>Second</td><td></td><td></td><td></td> </tr> <tr> <td>Third</td><td></td><td></td><td></td> </tr> <tr> <td>Fourth</td><td></td><td></td><td></td> </tr> </table>		Name		Contact number		Mail		Zip code		Address				Sales information	The shop's name			Address			Contact number	Zip code		Production Date	Sales date		Seller stamp			(Repair agency)				Number of repairs	Maintenance unit name	Maintenance reason	Repair time	first				Second				Third				Fourth			
Name		Contact number																																																					
Mail		Zip code																																																					
Address																																																							
Sales information	The shop's name																																																						
	Address																																																						
	Contact number	Zip code																																																					
	Production Date	Sales date																																																					
	Seller stamp																																																						
(Repair agency)																																																							
Number of repairs	Maintenance unit name	Maintenance reason	Repair time																																																				
first																																																							
Second																																																							
Third																																																							
Fourth																																																							

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.