

# WIFI SMART CAMERA

(Universal version)

## Quick Manual

### Operation

#### 1.Download APP

Tips one: Scan QR code.



iCSee

Tips two: Search "iCSee" in the App store and download.

#### 2.Start Up The Device

01. After installing the device in the corresponding position, connect the device to the corresponding power adapter.

After a few seconds, after you hear the "Start Quick Configuration" prompt from the camera, follow the step 3 02 Quick Configuration" operation.

#### Note:


If you need local storage, please install the memory card firstly, and then power on the device (the memory card does not support hot swapping, please plug and unplug the memory card when the device is powered off). Cloud storage is recommended, which is safe and convenient. Details See "Step 4" for operation.

### 3.Camera configuration

#### 01.User login

- Connect your phone to WiFi.
- Open the iCSee app, register an account and login(Figure 1).

Figure 1



#### 02.Quick configuration

- After successful login, Click the "+" button (Figure 2).
- Click the "WiFi Camera" ( Figure 3 ) .
- Set network configuration according to the camera's voice prompts and the APP interface step-by-step guide. When the camera emits a "Connect router successfully" prompt, it means that the camera has successfully configured the network.

**Note:** When camera is powered on, it will send "wait be connect" prompt after several seconds. Then you can go to next step(if the camera does not show the prompt for a long time, you can long press the camera reset button to restore the device to factory settings. When you hear the prompt " wait be connect" , it means entering the network configuration mode, if you don't hear any prompt sound for more than 10 seconds, short press reset button to wake up the device and network configuration again)

Figure 2






Figure 3



#### 03.Cloud storage


- After the network configuration is successful, follow the instructions on the APP interface to set the camera password and name.
- After the configuration is completed, the device is displayed in the device list interface. Click to open the real-time preview screen, and carry out relevant operations and settings(Figure 4).

Figure 4



#### 4.Cloud storage

- Steps to open cloud storage: click the "cloud storage" or "cloud" icon in the device list interface, and follow the guidance of the app interface to understand and open the cloud storage package, with a variety of packages available.



#### Cloud storage features:

- Cloud recording:** cloud storage of dynamic video recording will help you to check historic recording, and make sure video can not be stolen and damaged.
- Infinite space:** cloud storage can store alarm recording without quantity and video size limitation within the expiration date.
- Real time alarm:** Device will push short alarm video instantly to mobile when detect human wandering, which shows alarm scenery for timely controlling.
- Quick searching:** each dynamic video recording will be pushed to mobile as short video according to time sequence, which helps to increase recording searching efficiency.
- Safe and reliable:** All dynamic video recordings are encrypted and uploaded to the cloud for storage. Safe and reliable.

### Installation instructions

- Please confirm that the camera is successfully added before installation and fixation.
- The wall shall be able to bear at least 3 times the weight of the camera.
- Scan below QR code to view the detailed installation video tutorial.



### FAQ

#### Q: How does the camera store recordings?

- A: 1. Local TF card storage, maximum support 128G, automatically delete earlier videos after the TF card is full, and loop recording.
- 2. cloud storage.

#### Q: How to deal with the issue when forgot the device access password?

- A: Reconnect the device after restoring the device to factory settings and set a new password.

**Note:** The access password involves privacy and security, please treat it with caution.

#### Q: How to deal with the issue if the camera cannot be connected or abnormally offline during use?

- A: 1. Check whether the camera power supply and router network are normal.
- 2. Unplug and plug the power of the camera to restart the camera.
- 3. Restore the camera to the factory settings, and then re-add the device according to the instructions.

#### Q: Is 5g router supported ?

- A : If you use 5g router, 5G and 2.4G use the same connection hotspot (that is, SSID is the same), you can connect directly. If 5G and 2.4G are not the same connection hotspot (that is, SSID is different, generally SSID of 2.4G is xxxx-2.4G, SSID of 5G is xxxx-5G), please connect WiFi of mobile phone to hotspot of xxxx-2.4G of router before configuring camera.

### Notice

- 1. Please change the user password while using this product to avoid being misappropriated by criminals.
- 2. Do not install the device in a place that is damp, dusty, or accessible to children.
- 3. Please use and store within the allowable temperature and humidity range, and do not disassemble the equipment at will.

§ 15.19 Labelling requirements.  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.  
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.

### Directions

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

\*RF warning for Mobile device:  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### Warranty Card

- 1. Please refer to the actual product, the manual is for reference only.
- 2. The APP and product firmware will be updated from time to time. You can upgrade to the latest firmware online by yourself without notice. The manual is for reference only.
- 3. The manual may contain technically inaccurate parts or parts that are inconsistent with product functions or printed errors. Please refer to our company's final interpretation..

Warranty period: one year.  
This warranty card is only for our company's products.