



单张纸(风琴式折套)

## PISEN M1 磁吸蓝牙小音箱(国际版) (TP-YX01)\_说明书

材质：太阳60g双胶纸，双面印刷，1C  
展开尺寸：260×70mm，成品尺寸：52×70mm

版 本	修改内容	修改日期
R01/00		

Earphones

封面

PISEN®

M1

(TP-YX01)

User Manual

## Specifications

Model	TP-YX01
Dimensions	57*57*38.6 mm (2.24*2.24*1.52in)
Weight	Approx. 77.1g (2.72oz)
Endurance	Approx. 8 hours
Frequency/Response Range	80Hz-16KHz
Rated Voltage	3.7V
Transmission Distance	<10 m
Charging Time	Approx. 2 hours
Battery Capacity Of Earbuds	400mAh
Input	DC 5V=1A
FCC ID	2BQYD-TP-YX01
Accessories	Speaker*1 Type-C charging cable*1 User manual*1 Magnetic attraction plate*1 Lanyard*1

Data obtained from Pisen labs. Actual performance may vary based on usage scenarios and devices. For reference only.

## Friendly Reminders

Thanks for purchasing the M1 Magnetic Wireless Speaker. Please read this manual thoroughly to ensure safe and optimal use.

1.Product specifications and external design may change at any time due to improvements or upgrades.

2.The design and specifications are subject to change without prior notice.

3.Clear the speaker regularly with a dry cloth.

## Product Diagram

## Usage Instructions

### 1. Power On

Press and hold the power button for 3 seconds to turn on the speaker (Blue light stays on for 3 seconds, then LED indicator lights flash slowly).

### 2. Power Off

Press and hold the power button for 3 seconds to turn off the speaker.

Note: The speaker will automatically power off if no device is paired within 5 minutes.

### 3. Connecting a Device

When turned on for the first time, the speaker automatically enters pairing mode. On your device, search for the pairing name "Pisen M1" and tap to connect. You'll hear a voice prompt once connected (Indicator lights will pulse like breathing).








### 4. Auto-Reconnect

Once paired with a device (such as a phone), the speaker will automatically reconnect to the most recently connected device when powered on.

### 5. Disconnecting

The Bluetooth connection will drop if the speaker is more than 10 meters from the paired device. It will auto-reconnect if brought back within range within 5 minutes.

Note: The speaker will automatically shut down 5 minutes after disconnection.

<b>Button Functions</b>  <b>Music Playback</b> <p>Single-press the power button to pause or resume.</p> <b>Mode Switch</b> <p>Double-press the power button to switch to Game Mode; double-press again to return to Music Mode.</p> <b>Light Control</b> <p>Triple-press the power button to turn off the vibrant lights; triple-press again to turn them on.</p> 	<b>Indicator Lights &amp; Alerts</b> <ul style="list-style-type: none"><li>• <b>Pairing Status</b><p>Searching for a device: Vibrant lights flash slowly. Connected: Vibrant lights pulse.</p></li><li>• <b>Battery Alerts</b><p>A low battery notification will sound when the battery level drops to 10~20%.</p></li><li>• <b>Charging Status</b><p>Charging: Red indicator light stays on. Fully charged: Red indicator light turns off.</p></li></ul>	<b>Warning:</b> <ol style="list-style-type: none"><li>1. Store and use the product at room temperature.</li><li>2. Do not expose the product to salt or moisture.</li><li>3. Do not drop or throw the product, as this may cause damage.</li><li>4. Do not disassemble, repair, or modify the product yourself.</li><li>5. This product contains a non-replaceable lithium battery. Do not discard it carelessly, expose it to fire, or leave it in direct sunlight - this may pose a hazard.</li><li>6. Dispose of the battery according to local waste management rules. Whenever possible, recycle it. Do not dispose of with household waste to avoid environmental harm.</li></ol> <b>Kind reminders:</b> <ol style="list-style-type: none"><li>1. To avoid the hearing damage, please keep the volume at a moderate level and avoid listening to music at a high volume for a long time, as it may result in permanent hearing damage or deafness.</li><li>2. Please refrain from making phone calls or using earbuds while driving, cycling, crossing roads, or engaging in situations that require focused attention.</li><li>3. When watching videos with earbuds, the audio and video may get out of sync slightly.</li><li>4. If the earbuds are not used for a long time, please fully charge them at least once a month to extend the battery life.</li><li>5. If the earbuds are still connected or not charged after being put into the charging case, please wipe the stain on the charging contacts of earbuds to ensure good charging contact.</li><li>6. The output voltage and current of charger shall not exceed 5V/1A. If their specified values are exceeded, the product will be seriously damaged and the warranty will be voided.</li></ol>	<b>FCC Warning:</b> <p>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"><li>• Reorient or relocate the receiving antenna.</li><li>• Increase the separation between the equipment and receiver.</li><li>• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>• Consult the dealer or an experienced radio/TV technician for help.</li></ul> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	  Designed By Pisen      Made in China Manufactured by Guangdong PISEN Electronics Co., Ltd. Address: Building 5, 1st Floor, No. 9, Qinfu 1st Street, Lianyun Nan Community, Honggang Town, Longgang District, Shenzhen City, Guangdong Province, China  PISEN® The brand belongs to Guangdong PISEN Electronics Co., Ltd.  Contact: support@pisingroup.com    
6	7	8	9	

设计	黄运安	日期	2025-07-10	材料		成品规格	52×70mm	物料编码	物料名称: PISEN M1 磁吸蓝牙小音箱(国际版) (TP-YX01)_说明书
审核	杜志鸿	日期	2025-07-10	工艺		单位	mm	1.6.6.07.01.00.324	品胜股份 PISEN SHARES
批准	卢松	日期	2025-07-10	比例	1:1	公差	± 0.5mm		产品中心