



WIRELESS CHARGER

instructions

Qi Wireless Charger

English manual

Description:

Wireless charger for smartphones under the Qi-standard.
Easy to charge your phone without cables, just put your phone on the charging plate.

Specifications:

Input: According to the printing on the back of the charging plate.

Input: DC5V-2A

Output: DC5V-1A

Working Frequency: 110KHZ-220KHZ

Operating Temperature Range: -0~45°C

Storage Temperature Range: -10 ~50°C

Storage Humidity: 45% ~ 85% RH

Compatible with the Qi-standard.

Package contents:

Wireless charging plate

Adapter or Power cable

Power supply:

The charger is recommended to power by a qualified AC adapter.

Operation:

Connect the wireless charger to an outlet such as a qualified AC adapter, then a Led light is lit. Put your phone on the charging plate and the battery starts to charge, the Ledlight blinks during charging. If the phone doesn't start to charge, please try to reposition it.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user 's authority to operate the equipment.

Refer to KDB 784748 Anner A section A.5:

(a) Max. Electric Field Emissions: 6.06V/m Max.

Magnetic Field Emissions : 0.54A/m

(b) The maintenance of the system is the responsibility of the manufacturer.

(c) To prevent interference, the product should be as far away from devices operating at the same frequency as possible.

FCC ID: 2BCYB-0003743