



# STUNT RACER 360

## FUNCTIONAL DEMONSTRATION

### 1. TURN ON THE POWER, PAIR THE CAR AND THE REMOTE CONTROL

First turn on the remote control car switch and then turn on the remote control switch. After a successful pairing the light on the remote control goes out.

### 2. REMOTE CONTROL DISTANCE


The remote control operates vehicle up to 98ft.

### 3. TIME OF USE


On a full charge, the car lasts about 25 minutes.

### 4. INDICATOR LIGHT


When the car is turned on, the light flashes blue. After turning on the remote control switch, the car's light circle will change.



## BODY



## REMOTE CONTROL






USE 2 X 1.5V "AA"  
ALKALINE BATTERY  
(not included)




# STUNT RACER 360

## OPERATING INSTRUCTIONS



## WHEN THERE ARE OBSTACLES IN FRONT OF THE REMOTE CONTROL CAR:



# STUNT RACER 360

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.