

## Quick Start Guide

## Smart HD IP Camera



Please read the Quick Start Guide carefully before using the product and keep it properly.

Reminder: Please charge the device for 2 hours before using it.

## About this product

This manual is only a guide for related products and may differ from the actual product, please refer to the actual product. Due to product version upgrade or other needs, this manual may be updated without further notice!

This guide is applicable to various types of battery cameras. Some of the illustrations are based on battery camera.

## RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

## Packing list

Battery camera x1	Base x1	mounting guide sticker x1
Charging cable x1	3M Glue x1	Quick Start Guide x1
Screw package x1		

## Packing list

Camera x1	Charging cable x1	Solar panel x1(*option)
Mounting sticker x1	Quick Start Guide x1	Screw package x1

## The instructions of LED light :

- Green light flashes for 2s and goes out: The device is powered on and connecting to the network
- Green light + red light is always on: The camera is being previewed remotely (privacy light)
- Green light is always on: The device is connected to the network or awakened
- Green light flashes continuously: Upgrading
- Green light flashes continuously and slowly: Charging
- Red light flashes 3 times quickly: Power off
- Red light is always on: Low battery
- The traffic light is always off: In standby

## Button operation for single button model:

- Press the reset button and hold for 3s: Turn on
- Press the reset button 3 times continuously: Power off
- Press the reset button and hold for 5s in the power-on state: Reset

## Button operation for Two-button model:

- Press and hold the on/off button for 2s when shutting down: Turn on
- Press and hold the on/off button for 2s when powering on: Power off
- Press and hold the reset button for 3s: reset

## Boot up and Charging instructions

## 3.1 Boot up

1). When remote view by connecting to the router and direct connection method, please boot the device after inserting the SD card. When using by pairing to the wireless NVR, please make sure the memory(SD card, HDD etc.) of the wireless NVR is ready.  
2). During use, if it is found that the APP pushes low battery message or the camera has a low battery warning indicator, you need to charge the camera, as shown in the figure.

1. Dial the camera switch to "ON" to turn on.
2. Connect the camera to the solar panel.

Reminder: If the device does not turn on after turning the switch to ON, please insert the solar panel connection cable and place the solar panel in sunlight for 1-2 hours to charge, or plug in a household charger to charge before trying again.

## Note:

- Please use the original battery, and use the camera or the original charger to charge the battery.
- Using other batteries will result in inaccurate power display and may damage the camera.
- Please charge the battery at room temperature. If the temperature is too low or too high, the charging time will be extended, and the battery will be damaged and the battery life will be affected.

## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
— Reorient or relocate the receiving antenna.  
— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
— Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.