

Step 6: Adding your Cameras

This hub is compatible with multiple Night Owl Wi-Fi devices. When you choose to add a new camera, the app will ask you what type and walk you through the setup steps.


However, you can also scan the QR code below for more in-depth step-by-step instructions.



Step 7: Testing your Cameras

Ensure you test the connection and functionality of each camera you connect before you mount them. Check for signal strength in the desired placement location and adjust the placement if needed.

However, you can also scan the QR code below for more in-depth step-by-step instructions.




Step 8: microSD Card Setup

1. Insert the microSD card into the slot at the bottom of the hub.


2. Within the Night Owl app, go to the hub

settings to quickly format the microSD card.




Hard Disk Drive Storage (Optional)

1. Insert the microSD card into the slot at the bottom of the hub.
2. Within the Night Owl app, go to the hub settings to quickly format the microSD card.



TV or Monitor Viewing (Optional)

The hub can accommodate a 2.5" internal SATA HDD. To view and access your hub from a TV or monitor, simply connect an HDMI cable (not included) from the hub to your TV or monitor. You can use the app to adjust the layout.



Troubleshooting

1. Hub Not Connecting to WiFi: Ensure the WiFi network is working by checking signal strength in the desired placement location and adjust the placement if needed.

2. Devices Not Pairing with Hub:

• Check if the devices are compatible with the hub.

• Ensure devices are within range of the hub.

• Restart both the hub and the devices, then attempt to pair again.

3. Firmware Update Issues:

• Ensure the hub is connected to the internet.


• Do not unplug the hub during an update, a flashing blue and red light means it is correctly upgrading firmware.

• If the update fails, restart the hub, and try again.

4. Loss of Connection or Poor Signal:

• Avoid placing the hub near metal objects or electronic devices that can cause interference.

• Move the hub to a more central location in your home.



Factory Reset

Reseting the hub to factory default settings and purchase a compatible HDD from Night Owl.

1. Insert a USB flash drive into the USB port on the rear of the hub.

2. Go to the hub settings within the app to transfer the selected recordings.

LED Status Lights

For more help, please follow the steps below to access your Series support page:

1. Please visit: support.nightowlcam.com

2. Enter WiFi in the search bar as in the QR code.

Maintenance Tips

1. Regular Firmware Updates:

• Keep the hub firmware up to date for security and performance improvements.

• Turn on automatic updates if available.

2. Physical Maintenance:

• Dust the hub periodically to ensure proper ventilation.

• Keep the hub in a dry, temperature-controlled environment.

3. Regular Checkups:

• Periodically check the status of connected devices.

Transfer Recordings to a USB Drive

The hub can accommodate a 2.5" internal SATA HDD. To view and access your recordings to a USB drive for long-term storage or sharing. To do this:

1. Insert a USB flash drive into the USB port on the rear of the hub.

2. Go to the hub settings within the app to transfer the selected recordings.

Need Help?

For more help, please follow the steps below to access your Series support page:

1. Please visit: support.nightowlcam.com

2. Enter WiFi in the search bar as in the QR code.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance Statement: This device complies with FCC rules, Part 15. This device may cause interference to radio communications. However, the user is guaranteed that interference will not occur in all installations. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

CALIBRATION: The Federal Communications Commission (FCC) requires that changes or modifications not approved by the party responsible for the equipment's compliance could void the user's authority to operate the equipment. This equipment should be installed and operated with a minimum distance of 8 inches between the receiver and any body.

QS-FW-4-20-09

