

Bluetooth Speaker

function button

Power on/off (press for 3 seconds to turn on, for 5 seconds to turn off)

Play/pause (short press)

Pairing (press until indicator light flashes alternately in red and blue)

Adjust volume (Short press up/down +/-)

Last/Next (Long press up/down +/-)

Micro USB Charge Port

DC5V input (about 2h to get fully charged 3.7V 1200MAH Battery)

LED

Charging (Red LED On)

Fully charged (Red LED Lighting-off)

Short of power (Red LED flashes with beep warning)

Pairing (LED flashes alternately in red and blue)

Pair successfully (Blue LED flashes)

Off pair (Blue LED quickly flashes for 3 minutes and power off)

Procedure to Connect Mobile Phone

When Bluetooth Receiver is in the state of power off, long press multi-function button about 5 minutes until blue LED flashes, keep pressing until LED alternately flashes in red and blue waiting to be paired, then stop pressing.

Open Bluetooth of the mobile phone, click to search Bluetooth device, when phone receives the signal of the Bluetooth Receiver it will show model NO.HY-67.

Click HY-67 to connect. When successfully paired, blue LED of the Bluetooth Receiver flashes intermittently.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.