


DG05

## User Product Guide


### Product parameters



Product Model :DG05  
Waterproof level :IPX8  
Wireless version :V5.4  
Transmission distance :10M  
Memory support format: MP3, WMA, WAV, APE, FLAC, AAC, M4A  
Battery :180mAh  
Charging time: Approximately 2 hours  
Continuous usage duration :8-10 hours (70%volume)

Warm tip: Before swimming, please hold down the volume - key for a long time to switch to MP3 mode.


### Introduction to Key Functions



Turn on the machine  
Shut down  
Bluetooth(MP3)  
Answer the phone  
Hang up the phone  
Refuse to answer the phone  
Volume up  
Reduce the volume  
The next piece  
Part 1  
Play/Pause  
Voice assistant

Press and hold the power button for 3 seconds, and the red and blue light will alternate for 2 seconds. After that, the red light will remain on for 2 seconds  
Press and hold the power button for 2 seconds, and the red light will remain on for 2 seconds  
Press and hold the volume - key for 3 seconds  
Short press for multi-functional construction  
Short press for multi-functional construction  
Press the multi-function key for 2 seconds when there is an incoming call  
Press the volume + key briefly  
Press the volume - key briefly  
Double click multifunction key  
Three hit multi-functional construction  
Short press for multi-functional construction  
Press and hold the multi-function function for 2 seconds

### Pairing/Indicator light



Enter the pairing state: The device immediately enters the pairing mode upon startup. During the pairing state, the red light will alternate with the blue light. After entering the pairing state, turn on the Bluetooth on the device and search for the device name "DG05". Click on the device "DG05" to pair and connect. Once the connection is successful, you can use it.

When charging: The red light remains on at this time.

Low battery alert: The red light flashes when the battery is low, and the short sound reminds every 3 minutes.

Dual-mode switching: Press and hold the volume - key for 2 seconds to freely switch between Bluetooth and MP3(MP3 card) modes.

MP3(MP3 card) mode: Default sequential playback, with memory function.

File transfer on the computer: (Download the song)  
Connect the headphones to the computer with a magnetic data cable, and you can read them Headphone USB drive, in the folder, open the drive and select "DG05" file transfer to transfer out on the computer.

### Charging

1.This headset uses a built-in rechargeable battery. The battery must be fully charged when using the headset for the first time. During use, if the voice "Low battery" prompts low battery power, it indicates that the battery power is low. At this time, please charge the headset.

2. Connect the charging cable to the magnetic charging port of the headphones, and it will be fully charged in about 2 hours. The charging status indicator light remains on all the time, and the blue light is always on when fully charged.

### Warning!

1. Magnetic charging has positive and negative poles corresponding to each other. If they adhere to each other, charging can be normal; if they repeat each other, charging cannot be carried out and it even leads to brain damage.

2. The rechargeable battery of this product must be properly disposed of for recycling. Please do not put the battery away when the time is not used, causing an explosion.

### Precautions

1. Headphones should not be soaked in seawater or salt water for a long time. After use, wash the headphones with warm water and dry them with a soft cloth. Do not use a hard cloth or a sharp object to clean the headphones.

2. Please do not damage or assemble any components of the product by yourself. If you find any defect in the product, stop using it immediately. For use, contact the after-sales service of the seller for handling.

3. Please wipe the water off the surface of the headphones after each exercise, especially at the charging port and microphone port, to prevent water from getting into the headphones and causing damage to the headphones and affecting the service life of the product.

4. Please use the device away from the source of heat, moisture, freezing sources and chemicals. It is strictly forbidden to use the headphones in the sun or near the fire.

5. Keep the product in a dry place.

6. Please use a charger with an output of 5V or less. If the charging voltage is greater than 5V, it will cause the headphones to malfunction. Head may cause damage to the headphones.

7. Reorient or relocate the receiving antenna.

8. Increase the separation between the equipment and receiver.

9. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

10. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used in portable exposure without restriction.

CE RF ESD ROHS

Made in China