


T158 Bluetooth earphones
an instruction manual



Packing list



Product structure



Tips

1. Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the earbuds.
2. Don't put the earbuds in the water or any others liquid. The earbuds are not waterproof.
3. If any liquid enters the product by accidentally, please disconnect and remove the connection immediately.
4. Please make sure that there is no water on your hands when installing or uninstalling the product to avoid electric shock.
5. Do not put the product near by the heat source or expose it to the fire source directly.
6. Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product parameter

Headset parameters:
Bluetooth version: V5.3
Transmission distance: ≥10 M
Music time: About 5H(ANC on)/7H(ANC off)
Standby time: About 40 hours
Charging time: About 1 hours
Battery capacity: 40mAh/3.7V
Horn size: 10mm
Rated input: 5V== 120mA

Charging box parameters:
Battery capacity: 300 mAh/3.7V
Charging time: About 1.5 hours
Rated input: 5V== 300mA
(All technical information is subject to actual performance)

Charge the charging box Connect the charging box to the 5V power adapter with a Type-C charging cable.


The green light is on when the headset is charged, and the full electric light is off
The red light is flashing when the charging bin is charged, and the red light is on when the full electric light is on.

(Warm warning: low voltage warning, voltage below 3.2V (once every 60 seconds))

Product Operation Instructions

Power On: hold for 4 seconds or remove from charging bin
Power Off: hold for 6 seconds or place in charging bin
Pairing: When you start up, the device displays T158. Click Connect
Play/Pause: Click either headset
Top tune: Double click with left ear
Bend down: Double click on right ear
Volume reduction: Three strikes left ear
Volume plus: right ear three hits
Low delay mode switch: Press and hold for 2 seconds to switch the ANC MODE/NORMAL MODE/Transparency Mode
Answering a call: Click either side
Hong up: Click either side
Reject calls: Press and hold either side for 2 seconds
Low Battery: The voltage is lower than 3.4V (low battery every 60 seconds)

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○
This form is compiled in accordance with SJ/T 11364. O:Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572. X:Indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572. The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.						
Printed circuit board components: Including printed circuit boards and their parts, electronic components, etc and depending on the product model, the earbuds you purchased may not contain all the above components.						
 Electronic and electrical products sold in the People's Republic of China must mark this LOGO, the number in the logo represents the product under normal use Environmental protection use period						

Certificate of Approval
Product No.: _____
Production Time:  _____
QC: _____

Warranty statement

Disclaimer
This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired. Free repair; free replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale the ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 (13) months.
If you apply for a warranty please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of the three packs;
2. Altering the warranty card and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage obstacles or damage;
4. Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident body;
5. The zipper and tower buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product.
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.