


# Wireless charging mouse



Note: When using this mouse for the first time, please read this manual carefully to ensure the effectiveness of use.

## Installation method:

Step 1: Remove the receiver from the mouse battery compartment

Step 2: Plug the receiver into the USB port on your computer

Step 3: Turn on the power switch at the bottom of the mouse, and when the mouse cursor appears on the computer screen, you can use the mouse normally.

**Warm reminder:** When the mouse wheel flashing red indicates that the power is insufficient, charge in time, please choose the regular TYPE-C to charge the mouse for 2-3 hours to be full, when the green light, it means that it has been charged, do not charge for a long time.

## Note:

When using the mouse, keep away from strong interference sources, such as microwave ovens.

Clean the mouse with a small amount of anhydrous alcohol, do not place the entire mouse in the liquid.

**When the battery is used up, throw it into the battery recycling bin. Don't throw them in the trash, don't throw them away or throw them in the fire.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction