i🔒k

ZN84

User Manual

System Requirements

Wired Mode：Windows XP/ Vista/ Win7/ Win8/ Win10/Mac
2.4G Mode：Windows XP/ Vista/ Win7/ Win8/ Win10/Mac
BT Mode：Win7/Win8/Win10/Mac
Connector：USB（1.1/2.0/3.0/3.1）ports

Installation Steps

1- Take out the keyboard, insert the USB cable plug into the USB port of your computer, or insert the 2.4G receiver into the USB port of your computer, and turn on the keyboard power switch.
2-The system will automatically install the driver, if the installation fails, please restart the computer.
3-To the computer prompts the new hardware has been installed, at this time you can use your keyboard. Note: It is recommended to connect the USB2.0 interface.

Tips

1- The 2.4G mode and BT mode of this keyboard are powered by two AAA dry batteries.
2- No other liquids may enter the keyboard (otherwise the keyboard will be damaged).
3-Clean the keyboard regularly to avoid accumulating too much dust to affect the touch.

Connection Mode

Wired Mode: When the switch is toggled to OFF state, it will turn off the power of 2.4G mode and BT mode, at this time, after inserting the USB cable, it is wired connection mode.
2.4G mode: When the switch is toggled to 2.4G, it is 2.4G connection mode, the reporting rate is 125hz, and all lights on the keyboard are off.
BT Mode: When the switch is toggled to BT, it is BT connection mode, the reporting rate is 125hz, and all the lights of the keyboard are off.

BT Pairing

1. Default BT device name: BT1
2. BT mode can be connected to switch three devices at the same time: long press FN +1/2/3 key for 3 seconds for the corresponding BT pairing, BT pairing is complete, short press FN +1/2/3 key for the BT device to switch between the first time to switch to the BT mode, is automatically enter the broadcast state, the default is BT 1
3. With FN+HOME key, press and hold for 5 seconds to clear the BT pairing record, only in BT mode this conforming function is effective.

Independent Indicator Function

1-The first light, low power / low power shutdown value when the dry cell voltage is less than 2.2V, with the first red light, slow flashing (0.5HZ / 1 time) prompts, the work will be prompted all the time, the battery voltage is less than 1.8V, the keyboard stops working!
2-The second light, is a case tip red light, upper case when the red light is on, lower case when the light is off
3 - the third light, is WIN LOCK; lock, the indicator red light is on, no lock indicator off; (default is not locked, lock re-powered is unlocked)

Intelligent Power Saving Function

Keyboard in 2.4G and BT mode, more than 30 minutes without any key action automatically enter the power-saving hibernation state, enter the hibernation state after pressing any key to wake up the keyboard.

Operating System Switch

The Windows/Mac mode switch is located near the TYPE-C port of the keyboard, and you can switch between different system modes by switching left and right.,

| Ctrl / OPT | Win | Alt / CMD |

Shortcut Key Combination Functions

Pressing the FN key and the Function key at the same time will activate the second function of the Function key, the following is a description of the Function key and its function.

Key	Function	Key	Function	Key	Function	Key	Function
F1	Mute	F7	Button backlight speed slowed down	1 ! / ✳1	BT device 1	Pause / Scroll Lock	scrlock
F2	Volume down	F8	Key backlight speed up	2 @ / ✳2	BT device 2	Del / Insert	Insert
F3	Volume up	F9	Win key lock	3 # / ✳3	BT device 3	PgDn / Menu	Menu
F4	Key backlight on/off	F10	Web	4 $ / 2.4G	2.4G engineering pair code	End	Restore factory settings
F5	Key backlightbrightness increase	F11	My Computer	Home / BT	Clear Bluetooth pairing history	PgUp	Switch backlight monochrome light
F6	Key BacklightBrightness Decrease	F12	Backlight mode switching	PrtSc	Key Backlight Color Switching	Back	Turn on or off the side RGB light strip

i🔒k

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
    Reorient or relocate the receiving antenna.
    Increase the separation between the equipment and receiver.
    Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
    Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.